



# Operation Manual

PRODUCT NAME

Fieldbus system  
(SI unit compatible CompoNet)

MODEL / Series / Product Number

*EX12#-SCM#*

**SMC Corporation**




## Table of Contents

|                                       |    |
|---------------------------------------|----|
| Safety Instructions                   | 2  |
| Product Summary                       | 7  |
| Model Identification and How to Order | 7  |
| Names and Functions of Product        | 8  |
| Mounting and Installation             | 10 |
| Wiring                                | 10 |
| Setting                               | 14 |
| Mounting of Objects                   | 15 |
| Maintenance                           | 22 |
| Troubleshooting                       | 23 |
| Specification                         | 26 |
| Specifications                        | 26 |
| Dimensions                            | 27 |

## Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution", "Warning" or "Danger". They are all important notes for safety and must be followed in addition to International standards (ISO/IEC)\*<sup>1)</sup> and other safety regulations.

- \*1) ISO 4414: Pneumatic fluid power -- General rules relating to systems  
ISO 4413: Hydraulic fluid power -- General rules relating to systems  
IEC 60204-1: Safety of machinery -- Electrical equipment of machines (Part 1: General requirements)  
ISO 10218-1: Manipulating industrial robots -Safety.  
etc.

- |   |                  |  |
|---|------------------|--|
|  | <b>Caution</b> : | CAUTION indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.   |
|  | <b>Warning</b> : | WARNING indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury. |
|  | <b>Danger</b> :  | DANGER indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.     |

### Warning

**1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.**

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

**2. Only personnel with appropriate training should operate machinery and equipment.**

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

**3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.**

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

**4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.**

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

## Caution

### **The product is provided for use in manufacturing industries.**

The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.  
If anything is unclear, contact your nearest sales branch.

## **Limited warranty and Disclaimer/Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### **Limited warranty and Disclaimer**

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered.\*2)  
Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.  
This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

\*2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### **Compliance Requirements**

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulation of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

## Operator

- ◆ This operation manual is intended for those who have knowledge of machinery using pneumatic equipment, and have sufficient knowledge of assembly, operation and maintenance of such equipment. Only those persons are allowed to perform assembly, operation and maintenance.
- ◆ Read and understand this operation manual carefully before assembling, operating or providing maintenance to the product.

### ■ Precautions

#### Warning

- Do not disassemble, modify (including changing the printed circuit board) or repair.  
An injury or failure can result.
- Do not operate the product outside of the specifications.  
Do not use for flammable or harmful fluids.  
Fire, malfunction, or damage to the product can result.  
Verify the specifications before use.
- Do not operate in an atmosphere containing flammable or explosive gases.  
Fire or an explosion can result.  
This product is not designed to be explosion proof.
- If using the product in an interlocking circuit:
  - Provide a double interlocking system, for example a mechanical system.
  - Check the product regularly for proper operationOtherwise malfunction can result, causing an accident.
- The following instructions must be followed during maintenance:
  - Turn off the power supply
  - Stop the air supply, exhaust the residual pressure and verify that the air is released before performing maintenanceOtherwise an injury can result.

#### Caution

- After maintenance is complete, perform appropriate functional inspections.  
Stop operation if the equipment does not function properly.  
Safety cannot be assured in the case of unexpected malfunction.
- Provide grounding to assure the safety and noise resistance of the SI unit.  
Individual grounding should be provided close to the product with a short cable.

## ■NOTE

- Follow the instructions given below when designing, selecting and handling the product.
- The instructions on design and selection (installation, wiring, environment, adjustment, operation, maintenance, etc.) described below must also be followed.
  - \*Product specifications
    - The direct current power supply to combine should be UL1310 Class2 power supply when conformity to UL is necessary.
    - Use the specified voltage.  
Otherwise failure or malfunction can result.
    - Reserve a space for maintenance.  
Allow sufficient space for maintenance when designing the system.
    - Do not remove any nameplates or labels.  
This can lead to incorrect maintenance, or misreading of the operation manual, which could cause damage or malfunction to the product.
  - Precautions on handling
    - \*Installation
      - Do not drop, hit or apply excessive shock to the SI unit.  
Otherwise damage to the product can result, causing malfunction.
      - Tighten to the specified tightening torque. (refer to page 13)  
If the tightening torque is exceeded the mounting screws may be broken.
      - Never mount a product in a location that will be used as a foothold.  
The product may be damaged if excessive force is applied by stepping or climbing onto it.
    - \*Wiring
      - Avoid repeatedly bending or stretching the cables, or placing heavy load on them.  
Repetitive bending stress or tensile stress can cause breakage of the cable.
      - Wire correctly.  
Incorrect wiring can break the product.
      - Do not perform wiring while the power is on.  
Otherwise damage to the SI unit and/or I/O device can result, causing malfunction.
      - Do not route wires and cables together with power or high voltage cables.  
Otherwise the SI unit and/or I/O device can malfunction due to interference of noise and surge voltage from power and high voltage cables to the signal line.  
Route the wires (piping) of the SI unit and/or I/O device separately from power or high voltage cables.
      - Confirm proper insulation of wiring.  
Poor insulation (interference from another circuit, poor insulation between terminals, etc.) can lead to excess voltage or current being applied to the product, causing damage.
      - Take appropriate measures against noise, such as using a noise filter, when the SI unit is incorporated into equipment.  
Otherwise noise can cause malfunction.

#### \*Environment

- Do not use the product in area that is exposed to corrosive gases, chemicals, sea water, water or steam.  
Otherwise failure or malfunction can result.
- Do not use in an area where surges are generated.  
If there is equipment which generates a large amount of surge (solenoid type lifter, high frequency induction furnace, motor, etc.) close to the SI unit, this may cause deterioration or breakage of the internal circuit of the SI unit. Avoid sources of surge generation and crossed lines.
- Prevent foreign matter such as remnant of wires from entering the SI unit to avoid failure and malfunction.
- Mount the product in a place that is not exposed to vibration or impact.  
Otherwise failure or malfunction can result.
- Do not use the product in an environment that is exposed to temperature cycle.  
Heat cycles other than ordinary changes in temperature can adversely affect the inside of the product.
- Do not expose the product to direct sunlight.  
If using in a location directly exposed to sunlight, shade the product from the sunlight.  
Otherwise failure or malfunction can result.
- Keep within the specified ambient temperature range.  
Otherwise malfunction can result.
- Do not operate close to a heat source, or in a location exposed to radiant heat.  
Otherwise malfunction can result.

#### \*Adjustment and Operation

- Set the switches by using a sharp-pointed screwdriver etc.  
It may damage set switches.
- Perform settings suitable for the operating conditions.  
Incorrect setting can cause operation failure.  
For details of each setting, refer to page 14 of this manual.
- Please refer to the PLC manufacturer's manual etc. for details of programming and addresses.  
For the PLC protocol and programming refer to the relevant manufacturer's documentation.

#### \*Maintenance

- Turn off the power supply, stop the supplied air, exhaust the residual pressure and verify the release of air before performing maintenance.  
There is a risk of unexpected malfunction.
- Perform regular maintenance and inspections.  
There is a risk of unexpected malfunction.
- After maintenance is complete, perform appropriate functional inspections.  
Stop operation if the equipment does not function properly.  
Otherwise safety is not assured due to an unexpected malfunction or incorrect operation.
- Do not use solvents such as benzene, thinner etc. to clean the SI unit.  
They could damage the surface of the body and erase the markings on the body.  
Use a soft cloth to remove stains.  
For heavy stains, use a cloth soaked with diluted neutral detergent and fully squeezed, then wipe up the stains again with a dry cloth.


## Product Summary

EX12#-SCM# is an SI (serial interface) unit that can be connected to CompoNet.  
The following are the specifications and instructions for handling.

## Model Indication and How to Order


- SI unit series EX120

### EX120-SCM1




- Part number for accessories

### EX9-CCM1




### EX9-CP2






## Names and Functions of Product


### •EX120 series



### •EX121 series




### •EX122 series




| No. | Name                    | Purpose   |
|-----|-------------------------|---|
| 1   | Power supply connector  | Connect to the power supply for solenoid valve. |
| 2   | Communication connector | Connect to the CompoNet network.                |
| 3   | Display                 | The status of the unit is indicated by LED.     |
| 4   | Setting switch area     | For setting the node number.                    |
| 5   | Mounting bracket        | For mounting to a DIN rail.                     |
| 6   | MIL connector           | Connect to the solenoid valve.                  |

•Accessories


**Communication connector:** IDC connector for flat ribbon cable  
(EX9-CCM1: Not supplied with product)  
Applied when using a flat ribbon cable dedicated for use with CompoNet products.



**Communication connector:** Terminal block connector for round cable (VCTF)  
(EX9-CCM2: Not supplied with product)  
Applied when a VCTF cable is used.



**Power supply connector:** Straight type  
(EX9-CP2: 1 pc. supplied with product)




# Mounting and Installation


## ■Wiring

### •Internal circuit

- NPN (EX12#-SCM1)



- PNP (EX12#-SCM3)



## 1, Communication wiring

The network cable and communication connector for CompoNet are connected in the following manner.

### Note

The communication connector for the SI unit should be as shown below.

|   | Communication connector |          |                     |
|---|-------------------------|----------|---------------------|
|   | SMC                     | OMRON    | HONDA TSUSHIN KOGYO |
| For flat ribbon cable: IDC connector      | EX9-CCM1                | DCN4-BR4 | -                   |
| For round cable: Terminal block connector | EX9-CCM2                | -        | HCN-TB4LMZG+        |


We do not provide a tool that is used for wiring IDC connector.  
Please contact OMRON for further details.

### •Connection of IDC connector for flat ribbon cable

#### 1, Cutting of cable

Cut the cable vertically.


Use a tool with sharp edges such as a nipper to prevent short-circuit, and check there are no whiskers of wire sticking out.



#### 2, Connection of cable

Match the cable identification color with the color of the cable and insert the cable.

The cover is translucent to make it possible to check the cable reaches the end.



#### 3, Pressure-welding the connector

Use a tool (OMRON, DWT-A01) to connect wires.


(1) As shown below, place the connector cover so that its center (arrowed part) is at the center of the IDC block of the tool.



(2) Squeeze firmly on the DWT-A01 Pliers until the lock on the connector clicks into place.

**Note**

- Do not pressure-weld the connector cover at the edges.
- Do not pressure-weld the connector cover at the back of the pressure welding block.
- Set the connector in the correct orientation.



(3) After attaching the cable, confirm that it is properly pressure-welded.


No gap in this face



•Connection of terminal block for round cable


1, Removal of protective coating

Remove the protective coating, taking care not to damage the sheath of the internal signal cable.




2, Removal of sheath of signal cable

Remove the sheath of the signal cable to a length corresponding to the crimped part of the crimping terminal used.



3, Mounting of crimping terminal


Use the crimping terminal for wiring. Do not connect electrical wires which are just twisted directly to the terminal block.



4, Mounting to the connector

The available crimped terminal is M3 type.


The terminal screws should be firmly tightened to 0.3 to 0.5 Nm.



**2. Power supply wiring (Solenoid valve power supply)**

Connect the wiring for the solenoid valve power supply to the power supply connector (EX9-CP2).


Tighten the screw with 0.5 to 0.6 Nm of tightening torque.



Solenoid valve  
power supply 24 VDC

# Setting


## •LED indication



| Display | Meaning   |
|---------|---|
| PWR (V) | Solenoid valve power supply ON : Lights up<br>Solenoid valve power supply OFF : Goes off  |
| MS      | Unit in normal operation : Green lights up<br>Fatal error : Red lights up<br>Minor error : Red flashes<br>Power supply off : All lights go off  |
| NS      | On line/Connection completed : Green lights up<br>On line/Connection not completed: Green flashes<br>Fatal communication error : Red lights up<br>Minor communication error : Red flashes<br>Power supply off : All lights go off |

## •Switch setting

- The node setting is conducted using the rotary switch inside the unit cover.
- Make sure the switch setting is carried out with the power supply turned off.
- The switch should be set using a small flat screwdriver.



| Setting | Setting range |
|---------|---------------|
| x10     | 0 to 6        |
| x1      | 0 to 9        |

\*1: The station number should be any number from 00 to 63.  
If a node is set to a number greater than 63, the "NS" LED will light up.

After turning the power off, set to the correct number.

\*2: The address number cannot be duplicated.

## Mounting of Objects

This SI unit covers the CompoNet object classes below.

### Identity object (0x01)

|                 |            |                      |                        |                  |          |                       |
|-----------------|------------|----------------------|------------------------|------------------|----------|-----------------------|
| Object class    | Attributes | Unsupport            |                        |                  |          |                       |
|                 | Services   | Unsupport            |                        |                  |          |                       |
| Object instance | Attributes | ID                   | Meaning                | GET              | SET      | Value                 |
|                 |            | 0x01                 | Vendor ID              | O                | -        | 7 (7H)                |
|                 |            | 0x02                 | Device type            | O                | -        | 27 (1BH)              |
|                 |            | 0x03                 | Product code           | O                | -        | 128 (80H)             |
|                 |            | 0x04                 | Revision               | O                | -        | Per unit              |
|                 |            | 0x05                 | Status(bits supported) | O                | -        | Only bit0             |
|                 |            | 0x06                 | Serial number          | O                | -        | Per unit              |
|                 |            | 0x07                 | Product name           | O                | -        | EX12#-SCM#<br>(ASCII) |
|                 | 0x64       | Product Revision     | O                      | -                | Per unit |                       |
|                 | Services   | Cord                 | Meaning                | Parameter option |          |                       |
|                 |            | 0x05                 | Reset                  | -                |          |                       |
| 0x0E            |            | Get_Attribute_Single | -                      |                  |          |                       |

\*: The identify class is reset by software. Restart the unit after that.

### Message router object (0x02)

|  |            |           |
|--|------------|-----------|
| Object class                               | Attributes | Unsupport |
|  | Services   | Unsupport |
| Object instance                            | Attributes | Unsupport |
|  | Services   | Unsupport |
| Addition of vendor specific specifications |            | None      |

### Assembly object (0x04)

|                 |            |             |                           |  |  |                   |     |       |
|-----------------|------------|-------------|---------------------------|--|--|-------------------|-----|-------|
| Object class    | Attributes | Unsupport   |                           |  |  |                   |     |       |
|                 | Services   | Unsupport   |                           |  |  |                   |     |       |
| Object instance | Section    | Information |                           |  |  | Number of maximum |     |       |
|                 | Type       | Static I/O  |                           |  |  | 1                 |     |       |
|                 | Attributes | ID          | Meaning                   |  |  | GET               | SET | Value |
|                 |            | 0x01        | Number of Members in List |  |  | -                 | -   | -     |
|                 |            | 0x02        | Member List               |  |  | -                 | -   | -     |
|                 |            | 0x03        | Data                      |  |  | O                 | -   | -     |
|                 | Services   | Cord        | Meaning                   |  |  | Parameter option  |     |       |
|                 |            | 0x0E        | Get_Attribute_Single      |  |  | -                 |     |       |

### Digital I/O slave (Output)

| Instance  | Byte offset | Data |    |    |    |      |    |   |   |
|-----------|-------------|------|----|----|----|------|----|---|---|
|           |             | bit7 |    |    |    | bit0 |    |   |   |
| 35 (0x23) | +0          | 7    | 6  | 5  | 4  | 3    | 2  | 1 | 0 |
|           | +1          | 15   | 14 | 13 | 12 | 11   | 10 | 9 | 8 |



Connection object (0x05)

|              |            |      |                      |                  |     |       |
|--------------|------------|------|----------------------|------------------|-----|-------|
| Object class | Attributes | ID   | Meaning              | GET              | SET | Value |
|              |            | 0x01 | Revision             | O                | -   | 0001H |
|              | Services   | Cord | Meaning              | Parameter option |     |       |
|              |            | 0x0E | Get_Attribute_Single | -                |     |       |

|                 |                    |                                 |                                 |                  |                   |       |
|-----------------|--------------------|---------------------------------|---------------------------------|------------------|-------------------|-------|
| Object instance | Section            | Information                     |                                 |                  | Number of maximum |       |
|                 | Instance type      | POLL                            |                                 |                  | 1                 |       |
|                 | Production trigger | Cyclic                          |                                 |                  | -                 |       |
|                 | Transport type     | Server                          |                                 |                  |                   |       |
|                 | Transport class    | 3                               |                                 |                  |                   |       |
|                 | Attributes         | ID                              | Meaning                         | GET              | SET               | Value |
|                 |                    | 0x01                            | State                           | O                | -                 | -     |
|                 |                    | 0x02                            | Instance type                   | O                | -                 | 01H   |
|                 |                    | 0x03                            | Transport class trigger         | O                | -                 | 80H   |
|                 |                    | 0x04                            | Produced connection ID          | O                | -                 | -     |
|                 |                    | 0x05                            | Consumed connection ID          | O                | -                 | -     |
|                 |                    | 0x06                            | Initial comm. characteristics   | O                | -                 | 01H   |
|                 |                    | 0x07                            | Produced connection size        | O                | -                 | 64H   |
|                 |                    | 0x08                            | Consumed connection size        | O                | -                 | 64H   |
|                 |                    | 0x09                            | Expected packed rate            | O                | -                 | -     |
|                 |                    | 0x0C                            | Watchdog timeout action         | O                | -                 | 00H   |
|                 |                    | 0x0D                            | Produced connection path length | O                | -                 | 00H   |
|                 |                    | 0x0E                            | Produced connection path        | O                | -                 | -     |
|                 | 0x0F               | Consumed connection path length | O                               | -                | 00H               |       |
|                 | 0x10               | Consumed connection path        | O                               | -                | -                 |       |
|                 | Services           | Cord                            | Meaning                         | Parameter option |                   |       |
|                 |                    | 0x05                            | Reset                           | -                |                   |       |
|                 |                    | 0x0E                            | Get_Attribute_Single            | -                |                   |       |
| 0x10            |                    | Set_Attribute_Single            | -                               |                  |                   |       |

CompoNet Link object (0xF7)

| Object class    | Attributes | ID   | Meaning                | GET  | SET | Value |
|-----------------|------------|------|------------------------|--|-----|-------|
|                 |            | 0x01 | Revision               | O  | -   | 0001H |
| Object class    | Services   | Cord | Meaning                | Parameter option                               |     |       |
|                 |            | 0x0E | Get_Attribute_Single   | -  |     |       |
| Object instance | Attributes | ID   | Meaning                | GET  | SET | Value |
|                 |            | 0x01 | MAC ID                 | O  | -   | -     |
|                 |            | 0x02 | Data Rate              | O  | -   | -     |
|                 |            | 0x05 | Allocation choice      | O  | -   | -     |
|                 |            | 0x0A | Explicit message timer | O  | O   | -     |
|                 | Services   | Cord | Meaning                | Parameter option                               |     |       |
|                 |            | 0x0E | Get_Attribute_Single   | -  |     |       |
|                 |            | 0x10 | Set_Attribute_Single   | -  |     |       |
|                 |            | 0x4B | Allocate               | Allocation choice, EPR, Explicit message timer |     |       |
|                 |            | 0x4C | Release                | Release choice                                 |     |       |

Discrete Output Point (DOP) object (0x09)

| Object class | Attributes | ID                   | Meaning          | GET | SET                     | Value |
|--------------|------------|----------------------|------------------|-----|-------------------------|-------|
|              |            | 0x01                 | Revision         | O   | -                       | 0001H |
|              | 0x02       | Max Instance         | O                | -   | Number of output points |       |
| Services     | Cord       | Meaning              | Parameter option |     |                         |       |
|              | 0x0E       | Get_Attribute_Single | -                |     |                         |       |

| Object instance | Attributes | ID                   | Meaning                         | GET              | SET | Value   |
|-----------------|------------|----------------------|---------------------------------|------------------|-----|---|
|                 |            | 0x05                 | Fault Action                    | O                | O   | Sets the output condition for communication error.<br>0: Zero clear<br>1: Hold output<br>The set value is immediately reflected.                      |
|                 |            | 0x07                 | Idle Action                     | O                | O   | Setting of the output when the control is abnormal.<br>0: Zero clear<br>1: Hold output<br>The set value is immediately reflected.                     |
|                 |            | 0x65                 | Maintenance Counter Mode Choice | O                | O   | Setting of mode of maintenance counter<br>0: Energizing time mode (hour)<br>1: Contact counter mode (time)<br>The set value is immediately reflected. |
|                 |            | 0x66                 | Maintenance Counter             | O                | O   | Present value of maintenance counter<br>0 to 4294967295 (00000000 to FFFFFFFF H)  |
|                 |            | 0x67                 | Maintenance Counter Exceed      | O                | -   | Maintenance counter threshold over flag<br>0: Maintenance counter value < Threshold<br>1: Maintenance counter value > Threshold                       |
|                 |            | 0x68                 | Threshold Maintenance Counter   | O                | O   | Threshold of maintenance counter<br>0 to 4294967295 (00000000 to FFFFFFFF H)<br>The set value is immediately reflected.                               |
|                 | Services   | Cord                 | Meaning                         | Parameter option |     |   |
| 0x05            |            | Reset                | Only Attribute66                |                  |     |   |
| 0x0E            |            | Get_Attribute_Single | -                               |                  |     |   |
| 0x10            |            | Set_Attribute_Single | -                               |                  |     |   |

Unit Manager object (0x95)

|              |            |      |                      |                  |     |       |
|--------------|------------|------|----------------------|------------------|-----|-------|
| Object class | Attributes | ID   | Meaning              | GET              | SET | Value |
|              |            | 0x01 | Revision             | O                | -   | 0001H |
|              | Services   | Cord | Meaning              | Parameter option |     |       |
|              |            | 0x0E | GET_Attribute_Single | -                |     |       |

|                 |            |          |                                 |         |                  |   |  |
|-----------------|------------|----------|---------------------------------|---------|------------------|---|--|
| Object instance | Attributes | ID       | Meaning                         | GET     | SET              | Value   |  |
|                 |            | 0x65     | Generic Status                  | O       | -                | General purpose status *1   |  |
|                 |            | 0x6B     | Network Power Voltage           | O       | -                | Network power supply voltage<br>100 mV units<br>(BIN data)  |  |
|                 |            | 0x6C     | Max Network Power Voltage       | O       | -                | Max. network power supply voltage   |  |
|                 |            | 0x6D     | Min Network Power Voltage       | O       | -                | Min. network power supply voltage   |  |
|                 |            | 0x6E     | Threshold Network Power Voltage | O       | O                | Threshold of network power supply voltage. When the voltage falls below this set value, the status flag will turn on. The set value is immediately reflected. Default: 008CH (14.0 V) |  |
|                 |            | 0x71     | Run Hours                       | O       | -                | The unit for energizing time of internal power circuit with the product. Hour<br>0 to 4294967295 (00000000 to FFFFFFFF H)   |  |
|                 |            | 0x72     | Run Hours Exceed                | O       | -                | Energizing time threshold over flag<br>0: Energizing time < Threshold (default)<br>1: Energizing time >= Threshold  |  |
|                 |            | Services | Cord                            | Meaning | Parameter option |   |  |
|                 |            |          | 0x05                            | Reset   | Attribute6C, 6D  |   |  |
|                 | 0x0E       |          | Get_Attribute_Single            | -       |                  |   |  |
|                 | 0x10       |          | Set_Attribute_Single            | -       |                  |   |  |

\*1: General purpose status

| Bit | Names                       | Explanation  |
|-----|-----------------------------|--|
| 0   | -                           | -  |
| 1   | -                           | -  |
| 2   | Network Power Warning       | The network power supply voltage has fallen below the threshold value.<br>When it has fallen below the threshold: ON |
| 3   | UNIT Total time Warning     | The total energizing time of the product has exceeded the threshold value.<br>When it has exceeded the threshold: ON |
| 4   | -                           | -  |
| 5   | -                           | -  |
| 6   | Response Time Warning       | Any of monitored operation time is outside of range: ON  |
| 7   | Maintenance Counter Warning | Any of output monitored operation time is outside of range: ON   |

Communication Error Log object (0x96)

| Object class | Attributes | ID   | Meaning              | GET              | SET | Value |
|--------------|------------|------|----------------------|------------------|-----|-------|
|              |            | 0x01 | Revision             | O                | -   | 0003H |
|              |            | 0x02 | Max Instance         | O                | -   | 0004H |
| Object class | Services   | Cord | Meaning              | Parameter option |     |       |
|              |            | 0x0E | Get_Attribute_Single | -                |     |       |

| Object instance | Attributes | ID   | Meaning               | GET              | SET | Value  |
|-----------------|------------|------|-----------------------|------------------|-----|--|
|                 |            | 0x64 | Error Code            | O                | -   | Error code<br>0: No error<br>1: Connection<br>Time out<br>2: Unused<br>3: MAC ID duplicated<br>Repeater<br>configuration error |
|                 |            | 0x67 | Network Power Voltage | O                | -   | Network voltage<br>when error occurs   |
|                 |            | 0x68 | Run Hours             | O                | -   | Energizing time<br>when error occurs.<br>Hour  |
|                 |            | 0x69 | Manchester Error Rate | O                | -   | Error code   |
| Object instance | Services   | Cord | Meaning               | Parameter option |     |  |
|                 |            | 0x05 | Reset                 | -                |     |  |
|                 |            | 0x0E | Get_Attribute_Single  | -                |     |  |

Equipment Manager object (0x97)

| Object instance | Attributes | ID                   | Meaning                 | GET | SET | Value  |
|-----------------|------------|----------------------|-------------------------|-----|-----|--|
|                 |            | 0x65                 | Response time           | O   | -   | Machine response time of output point with the product [ms]  |
|                 |            | 0x66                 | Response time exceed    | O   | -   | Relation of response time of machine to threshold of output point with the product<br>0: Within threshold<br>1: Over threshold |
|                 |            | 0x67                 | Threshold Response Time | O   | O   | Response time of machine of output point with the product units [ms]<br>The set value is immediately reflected.                |
|                 |            | 0x68                 | Response time peak      | O   | -   | Peak value of response time of machine   |
| Services        | Cord       | Meaning              | Parameter option        |     |     |  |
|                 | 0x05       | Reset                | Attribute68             |     |     |  |
|                 | 0x0E       | Get_Attribute_Single | -                       |     |     |  |
|                 | 0x10       | Set_Attribute_Single | -                       |     |     |  |

# Maintenance

## Mounting and wiring

| Item to inspect   | Criteria              | Countermeasure  |
|---|-----------------------|---|
| Confirm the connectors (communication, power supply) of the SI unit are securely connected. | No looseness.         | Tighten the connector screws. (refer to "Mounting/Installation" on page 10) |
| Confirm the connecting cable is not broken.   | No signs of breakage. | If any breaks are found, replace the cable.                                 |

## Replacement parts

| Item to inspect                    | Criteria   | Countermeasure  |
|------------------------------------|--|---|
| Cable for moving parts (when used) | No signs of breakage and no error in the conductive resistance value. (For the resistance value, check for exceeding of specified range and balance change in pair cable.) | If any breaks and found, or the conductive resistance is incorrect, replace the cable. Refer to the cable specifications for the conductive resistance. |
| SI unit                            | No error in operation and display.   | If any error is found in the operation or on the display, replace the unit.   |

## Power supply

| Item to inspect  | Criteria   | Countermeasure   |
|--|--|--|
| Confirm the voltage is within the specified range. Measure the voltages at both sides of the power supply for CompoNet.        | 14 VDC to 26.4 VDC   | Investigate the cause of the voltage fluctuation, and take countermeasures against it. |
| Confirm the voltage is within the specified range. Measure the voltages at both sides of the power supply for solenoid valves. | 24 VDC +10%/-5% (refer to "Unit specification" on page 26) |  |


# Troubleshooting

## •Troubleshoot

Applicable model: **EX12\*-SCM\***

If a SI unit gets an operation failure, look for the problem using the following flow chart.

If any cause of the problem cannot be found, and a new SI unit can operate well after replaced with the old one, the failure of SI unit is conceivable. As the failure of SI unit may happen due to the operation environment (network construction etc), consult us about the countermeasure against that case.





●List of Troubles and Countermeasures

| Trouble No. | Problem                                     | Possible cause                    | Investigation method  | Countermeasure  |
|-------------|---|-----------------------------------|---|---|
| 1           | MS_LED at SI unit goes off                  | Failure of wiring                 | Check the communication power supply cable is not opened, and that there are no loose connections between the power supply cable and terminal.<br>Check there is no repeated bending and pulling force applied to the cable, which will cause breakage. | Connect the power supply cable correctly.                               |
|             |   | Failure in power supply           | Check proper wiring of communication power supply.  | Correct the wiring.   |
|             |   |                                   | Check the supply voltage to the power supply  | Supply 14 VDC to 26.4 VDC to the power supply for SI unit.              |
| 2           | Red light of MS_LED at SI unit is lit up    | Failure in SI unit                | The product has failed.   | Replace the SI unit with a new one.                                     |
| 3           | Red light of MS_LED of SI unit is blinking  | Incorrect setting of node address | Check there is no mistake with the set node address.  | Set correctly.  |
| 4           | SI unit MS_LED green on NS_LED goes off     | Master unit power supply failure  | Check the master unit is operating properly.  | Connect the master unit to a proper power supply.                       |
| 5           | SI unit MS_LED green on NS_LED red on       | Duplication of node address       | Check the set node address is not duplicated by other slave units.  | Set correctly.  |
| 6           | SI unit MS_LED green on NS_LED red blinking | Communication timeout             | Check the communication cable is not opened, and that there are no loose connections between the power supply cable and terminal.<br>Check there is no repeated bending and pulling force applied to the cable, which will cause breakage.              | Connect the communication cable correctly.                              |
|             |   |                                   | Check proper wiring of communication cable.   | Correct the wiring.   |
|             |   |                                   | Check the terminal resistance (121 Ω) is installed only at both ends of the main line.  | Install the terminal resistance (121 Ω) properly.                       |
|             |   |                                   | Check proper length of the cable (main line and branch line).   | Correct the wiring.   |
|             |   |                                   | Check the existence of equipment and high voltage line, which cause noise, around the communication and power supply lines.   | Separate the cables for communication and power from the noise sources. |
|             |   |                                   | Check that all slaves are properly set.   | Correct the wiring.   |

| Trouble No. | Problem  | Possible cause                                      | Investigation method  | Countermeasure   |
|-------------|--|---|---|--|
| 7           | SI unit<br>MS_LED green on<br>NS_LED green<br>blinking               | Connecting  | Check the master unit is operating properly.  | Refer to the Operation Manual of the master unit.  |
|             |  |   | Check the I/O area of the slave unit is not over the area permitted by the master unit.   |  |
| 8           | SI unit<br>MS_LED green on<br>NS_LED green on<br>PWR(V)_LED goes off | Incorrect wiring of valve power supply              | Check the valve power supply cable is not opened, and that there are no loose connections between the power supply cable and terminal.<br>Check there is no repeated bending and pulling force applied to the cable, which will cause breakage. | Connect the valve power supply cable correctly.  |
|             |  | Valve power supply failure                          | Check there is no incorrect wiring of valve power supply.   | Correct the wiring.  |
|             |  |   | Check proper supply voltage of valve power supply.  | Supply 24 VDC -5% +10% to valve communication power supply.  |
| 9           | Valve malfunction  | Valve failure                                       | Check the operation with another valve.   | Check the troubleshooting for a valve.   |
|             |  | Connection failure between SI unit and manifold.    | Check the connector between SI unit and manifold for the connection failure such as a bent pin  | Correct the connection between SI unit and manifold.   |
|             |  | Valves over a total of 16 outputs will not operate. | Check the total number of outputs of the valves connected to the manifold is 16 or less.  | The max. number of outputs of the product is 16. Be sure to keep the number of outputs 16 or less. |

# Specification

## ■ Specifications

### ● Unit specifications

| Model                               |                                     | EX12*-SCM1  | EX12*-SCM3  |
|-------------------------------------|-------------------------------------|---|-------------|
| Power supply voltage                | For unit                            | 14 VDC to 26.4 VDC  |             |
|                                     | For valve                           | 24 VDC +10%/-5% *1  |             |
| Internal current consumption (unit) |                                     | 100 mA or less  |             |
| Output specification                | Output type (Valve common polarity) | NPN (+COM.)   | PNP (-COM.) |
|                                     | Output points                       | 16 points   |             |
|                                     | Connection load                     | 24 VDC<br>Solenoid valve with a light and surge voltage suppressor of 2.1 W or less, made by SMC                |             |
|                                     | Output of communication error       | Hold/Clear (set through network)  |             |
| Environment proof                   | Enclosure                           | IP20  |             |
|                                     | Operating temperature range         | 0 °C to 55 °C (8 valves on)<br>0 °C to 50 °C (16 valves on)   |             |
|                                     | Operating humidity range            | 35% to 85%RH (no dew concentration)   |             |
|                                     | Withstand voltage                   | 1000 VAC, 1 min. Between external terminals and body  |             |
|                                     | Insulation resistance               | 500 VDC, 2 MΩ or more Between external terminals and body   |             |
|                                     | Operating environment               | No corrosive gas  |             |
|                                     | Pollution degree                    | For use in Pollution Degree 2 Environment   |             |
| Standard                            |                                     | CE marking  |             |
| Weight                              |                                     | EX120-SCM#: 100 g or less<br>EX121-SCM#: 120 g or less<br>EX122-SCM#: 110 g or less } (Contain the accessories) |             |
| Accessory                           |                                     | Power supply connector 1 pc. (EX9-CP2)  |             |

\*1: The condition for allowable voltage fluctuation to solenoid valve is 24 VDC±10%.




Please confirm the allowable voltage fluctuation range of solenoid valve that is installed in SI unit and set the power supply voltage in consideration of Max. 5% voltage drop across SI unit.

### ● Communication specifications




| Model                               | Specifications                          |
|-------------------------------------|---|
| Protocol                            | CompoNet™                               |
| Communication speed                 | 93.75 kbps/1.5 M/3 M/4 Mbps             |
| Setting file                        | EDS file (downloaded from our web site) |
| Occupied area (No. of input/output) | 0/16                                    |

■Dimensions (unit: mm)




- EX120-SCM\*



●EX121-SCM\*



●EX122-SCM\*



Revision history

A: Add the contents.

# SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN

Tel: +81 3 5207 8249 Fax: +81 3 5298 5362

URL <http://www.smcworld.com>

---

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.  
© 2009-2010 SMC Corporation All Rights Reserved

