

LF19 Pressure Switch


LEFOO

LF19 pressure switch can also be used to regulate the tank pressure between two pre-set values on one phase electrically driven air compressors. It is available with an unloader valve, which prevents compressors from starting under load, and it is available with an On-Off knob for manual cut off the compressor.



Specification

Model	LF19	LF19
Media	Water	Water
Unloader Valve	None	None
Min on (Cut In)PSI	1.0bar	2.0bar
Max Off (Cut Out)PSI	6.0bar	11.0bar
Differential	1.0-3.5bar	2.0-4.0bar
Factory Setting	2.0-3.0bar	4.0-6.0bar
Electrical Rating	250VAC,16A	250VAC,16A
Contact Arrangement	Normal Close (NC)	Normal Close (NC)




Conversion: 1Kgf/cm²=14.2PSI 1Bar=14.5PSI

尺寸单位: mm
(Dimension in mm)

LF19 Order Ref No:

i.e.: LF19-1111-2.0bar-3.0bar



Number	Connection Type		Connection Size	Handle Type
0	/	/	/	Without
1	Single Port	Female	G1/4	ON/OFF Knob
2	/	Male	G1/2	/
3	/	/	1/4NPT	/
4	/	/	1/2NPT	/
5	/	/	R1/4	/
6	/	/	R1/2	/