




# *Spare parts suitable for:* **SILKO**

S

Suitable for Silko

## *Spare parts suitable for modular ranges*



**G.E.V. Großküchen-Ersatzteil-Vertrieb GmbH**  
Robert-Koch-Straße 3a  
82152 Planegg/Munich  
Germany

Phone: +49 (0)89 745572-0  
Fax: +49 (0)89 745572-83  
order@gev-online.com  
www.gev-online.com

Member of the  **GEV GROUP**


# TABLE OF CONTENTS

## Open tops (gas/electric)



page 4

## Ovens (gas/electric)



page 9

## Fry tops (gas/electric)



page 10

## Lava rock grills (gas)



page 13

## Chargrills (electric), bratt pans (electric)




page 13




# TABLE OF CONTENTS

## Pasta cookers (gas/electric)



page 14

## Bains-marie (gas/electric)



page 16

## Sausage roasters/chip scuttles



page 17

## Fryers (gas/electric)




page 18

## Tilting bratt pans (gas/electric)



page 22

## Boiling pans (gas/electric)



page 26

## Open tops (gas)



Item	Order	Description	Model	OEM
1	103066	burner cover, Ø80mm		0100250
2	103065	burner ring	RGB654/658,	0100249
3	104100	burner lower part	SC45/46TOP,	0100259
4	104101	jet holder	CCGG__	0100260



Item	Order	Description	Model	OEM
1	103068	burner cover, Ø100mm		0100248
2	103067	burner ring	RGB654/658,	0100247
3	104102	burner lower part	SC45/46TOP,	0100261
4	104103	jet holder	CCGG__	0100258



Item	Order	Description	Model	OEM
1	102062	thermocouple, 600mm		0100812
2	102067	nut, M8x1		-
3	101491	gas tap	RGB654/658,	0100730
4	110723	knob	SC45/46TOP,	0101953
			CCGG__	0101234
5	111512	knob, S-shape		0101786



Item	Order	Description	Model	OEM
1	100729	electrode	RGB654/658,	0100833
			SC45/46TOP,	
			CCGG__	
2	100037	ignition cable, 600mm	RGB654/658,	0100898
3	100003	piezoelectric igniter	SC45/46TOP	0100898
4	100197	ignition cable, 600mm	CCG6__	0101681
5	100009	piezoelectric igniter		0100895



Item	Order	Description	Model	OEM
1	103069	burner cover, Ø75mm		0100252
2	104104	burner head	CG7__,	0100208
			ST76__,	0100298
3	104105	Venturi	CCG7__,	0100206
			CCT70__	0100301
4	104108	jet rod		0100767



Item	Order	Description	Model	OEM
1	103070	burner cover, Ø95mm		0100251
2	104106	burner head	CG7__, ST76__,	0100209
			CCG7__, CCT70__,	0100299
3	104107	Venturi	CCG9__, CC906,	0100207
			CCG10__	0100302
4	104108	jet rod		0100767




Item	Order	Description	Model	OEM
1	105300	burner cover, Ø110mm	CG7__, ST76__,	0100253
2	104294	burner head	CCG7__,	0100216
			CCT70__,	0100300
3	105301	Venturi	CCG9__, CC906,	0100217
			CCG10__	0100303
4	104108	jet rod		0100767




Item	Order	Description	Model	OEM
1	102040	thermocouple, 400mm		0100808
1	102042	thermocouple, 850mm	CG7__, ST76__,	0100809
2	101491	gas tap	CCG7__,	0100730
3	110723	knob	CCT70__,	0101953
			CCG9__, CC906,	0101234
4	111512	knob, S-shape	CCG10__	0101786

S


Suitable for Silko




Item	Order	Description	Model	OEM
1	101454	electrode screw connection	CG7_, ST76_	0100620
2	101452	electrode holder	CCG7_	LB839-00
3	101453	thermocouple holder	CCT70_	LB838-00
4	100907	thermocouple screw connection	CCG9_, CC906, CCG10_	0100817



Item	Order	Description	Model	OEM
1	100733	electrode with knob, 600mm	CG7_	0100834
2	100003	piezoelectric igniter	ST65_	0100898
3	100010	ignition switches		0101188
4	100745	electrode with cable, 550mm	CCG_	9300542
4	100746	electrode with cable, 950mm	CCT70_	9300541
4	100747	electrode with cable, 1350mm	CCT906_	9300540




Item	Order	Description	Model	OEM
1	101012	ignition unit, 2-compartment	CCG_	0101193
2	101023	ignition unit, 4-compartment	CCT70_	0101194
3	101024	ignition unit, 6-compartment	CCT906_	0101195



Item	Order	Description	Model	OEM
1	103008	burner cover, Ø90mm	CV7_, TG765,	0100244
2	104008	burner base, Ø90mm	CVL_, CV4_	0100232
3	103009	burner cover, Ø130mm	CV6_, CV8_	0100246
4	104009	burner base, Ø130mm	TG65	0100234



Item	Order	Description	Model	OEM
1	104011	Venturi	CV7_, TG765,	0100256
2	104012	aeration tube	CVL_, CV4_	0100257
3	104010	jet holder	CV6_, CV8_	0100255
			TG65	



Item	Order	Description	Model	OEM
1	100054	pilot burner/left		0100799
2	100053	pilot burner/right	CV7_, TG765,	0100800
3	100701	electrode	CV2_, CV4_	0100831
4	100199	ignition cable, 600mm	CV6_, CV8_	0101631
5	100003	piezoelectric igniter	TG65	0100898




Item	Order	Description	Model	OEM
1	210163	top grate	RGB654/658, SC45, SC46TOP	0101829
2	n.l.a.	top grate	CCG6020/40	0101065 0101066
3	210187	top grate	CCG6045/6, CG60652/53/63	6200291



Item	Order	Description	Model	OEM
1	n. l. a.	top grate	CG701	0101831
2	n. l. a.	top grate	CG721/22/41/42, CG745/61/62/64/66	0101823
3	n. l. a.	top grate	CV721/22/41/45, CV745/61/65/66	0101815 0101817






no longer available



Item	Order	Description	Model	OEM
1	210156	top grate	CCG7020/21/22/40/41/42, CCG7045/46/61/62/65/ 653, CCG7001, CCT7040R/ 402, CCT7041R/412/42R/ 42L/45R/45L, CCT70652/ 53/52L/53L	0101808 0101807
2	no longer available	top grate	CV20/21/22/40/41/42/44/ 45, CV60/61/62/65/66/81/85	0101814 0101816
3	210159	top grate	CCG9__	9203237



Item	Order	Description	Model	OEM
1	210050	reducing star, steel chromium-plated	universal (CV)	0101080
1	210001	reducing star, stainless steel	-	-
2	210004	reducing star, steel chromium-plated	CV7__	0101082
3	210003	reducing star, steel chromium-plated	CV2__, CV4 __, CV6__, CV8__	0101081

## Open tops (solid top)



no longer available

Item	Order	Description	Model	OEM
1	n. l. a.	burner, 1/1	ST79__/L, ST76__/R,	0100276
2	105534	burner, 1/2	TG765, ST74__	0100282




Item	Order	Description	Model	OEM
1	105251	burner, 1/1	CTT70__, CTT90__	0100294
2	105535	burner	TG4__, TG65	0100274




Item	Order	Description	Model	OEM
1	102040	thermocouple 500		0100808
2	101397	gas tap PEL21	ST765/766, CTT70__/L,	0100731
3	111513	knob	CTT70__/R	0101954
4	111514	knob, S-shape		0101798



Item	Order	Description	Model	OEM
1	102042	thermocouple		0100809
2	101086	gas tap PEL22	ST76__/L, ST76__/R, ST74__, CTT70__,	0100732
3	110729	knob	TG65, TG4__, CTT90__	0101211 0101965
4	111515	knob, S-shape		0101787




Item	Order	Description	Model	OEM
1	102042	thermocouple		0100809
2	101087	gas tap PEL22		0100733
3	110729	knob	TG765	0101211 0101965
4	111515	knob, S-shape		0101787




Item	Order	Description	Model	OEM
1	100046	pilot burner		0100822 0100824
2	100706	electrode	ST65/766, ST74__, ST76__/R, ST76__/L,	0100832
3	100199	ignition cable, 600mm	CTT70__/L,	0109082
3	102155	ignition cable, 900mm	CTT70__/R, TG65	0101629
4	100003	piezoelectric igniter		0100898

Suitable for Silko



Item	Order	Description	Model	OEM
1	100076	pilot burner		0101047
2	100701	electrode	CTT70__, CTT90__	0100831
3	102155	ignition cable		0101629
4	100010	ignition switches		0101188



Item	Order	Description	Model	OEM
1	300025	7-position knob, 16A		0101423
2	300106	7-position knob, 32A	RB654/658,	0101399
3	110720	knob	CCT60__, CET7__, ET7__, CE7__, EQ7,	0101210 0101957
4	111516	knob, S-shape	CCQ7__	0101790
5	359291	signal lamp (green)	CE2__, CE4__, CE6__, CCQ9__	0101169




Item	Order	Description	Model	OEM
1	101012	ignition unit, 2-compartment		0101193
2	101023	ignition unit, 4-compartment	CTT70__, CTT90__	0101194
3	101024	ignition unit, 6-compartment		0101195

Open tops (ceramic)



Item	Order	Description	Model	OEM
1	490024	1200W/230V		0101465
2	490025	1700W/230V	CCT__/V	0101466
3	490008	4000W/400V	CCQ9__/V	0101468



Item	Order	Description	Model	OEM
1	100054	pilot burner		0100799
2	100701	electrode		0100831
3	100199	ignition cable, 60mm	TG4__	0109082
4	100003	piezoelectric igniter		0100898

Open tops (electric)



Item	Order	Description	Model	OEM
1	490020	2600W/230V, 220mm	RB654/658,	0101482
1	490018	2000W/230V, 220mm	CCT60__, CET7__, ET7__	0101487
2	490066	2600W/230V, 220x220mm	CE7__, EQ7,	0101475
2	490065	2000W/230V, 220x220mm	CCQ7__	0101474
3	490070	3000W/230V, 300x300mm, without Predector		
3	490056	3000W/230V, 300x300mm, with Predector	CE2__, CE4__, CE6__, CCQ9__	0101467
3	490071	4000W/230V, 300x300mm		0101476




Item	Order	Description	Model	OEM
1	380015	energy regulator		0108231
2	110721	knob		0101956 0101207
3	111517	knob S-shape		0101789
4	359291	signal lamp		0101169


## Ovens (gas)




Item	Order	Description	Model	OEM
1	105257	burner	SC45, SC46TOP, CCG6045, CCG60652/3	0100280
2	105536	burner	CG701	0100269
3	105258	burner	CV721/2, CV741/2/5, CV761/5/6	0100272
4	105250	burner	CCG7001, CTT9045, CTT90652/3, CTT90663R	0101051




Item	Order	Description	Model	OEM
1	102042	thermocouple, 850mm	CCG6045, CCG60652/3, CCG7045, CCG70652/3, CCG7001, CCT7045, CTT70652/3, CCG9045/85,	0100809
1	102045	thermocouple, 1500mm	CCG90652/3, CCG90852, CTT9045, CTT90663, CTT90652/3	0100818
2	101125	Eurosit controller		0100873 KVL0001 KVL0005




Item	Order	Description	Model	OEM
1	105537	burner	CG721/2, LG741/2/5, CG761/2/5/6, ST765/6, CCG7045, CCG70652/3, CCT7045, CCT70652/3	0100277
2	105538	burner	CV45, CV65, CV85, TG65, TG45	0100266



Item	Order	Description	Model	OEM
1	102042	thermocouple	CV745, CV765,	0100809
2	101438	Minisit	TG765, TG65/45	0100855
3	101136	cover with Piezo		0100857



Item	Order	Description	Model	OEM
1	102045	thermocouple		0100818
2	101076	gas thermostat	SC45, SC46TOP, CG701, CG745, CG765/6, ST765/6, ST745	0100724
3	n. l. a.	knob		0101227
4	111522	knob, S-shape		0101785




Item	Order	Description	Model	OEM
1	100046	pilot burner	SC45, SC46TOT, CCG6045,	0100824
2	100706	electrode	CCG60652/3, CG745, CG765/6, ST765/6, ST745, CCG7045, CCG70652/3	0100832
3	102158	ignition cable, 1700mm		0101632
4	100003	piezoelectric igniter		0100898




Item	Order	Description	Model	OEM
1	100076	pilot burner	CG701, CCG7001,	0101047
2	100701	electrode	CCG9045/85, CCG90652/3,	0100831
3	102158	ignition cable, 1700mm	CCG90852, CCT9045,	0101632
4	100003	piezoelectric igniter	CCT9652/3	0100898






Item	Order	Description	Model	OEM
1	100053	pilot burner		0100800
2	100701	electrode	TG765, TG45	0100831
3	100026	ignition cable, 1000mm		-
4	100001	piezoelectric igniter		-


## Ovens (electric)



Item	Order	Description	Model	OEM
1	415341	735W/230V	CCG60652/3, CCT6046	0101556
2	415294	900W/230V	ET745/65, CCT7046/70663, CCQ7046/70663	0101554
3	415395	800W/230V	SCE46	0101553




Item	Order	Description	Model	OEM
1	415131	2500W/3 phases 230V	CE745, CET745	0101506
2	415252	2750W/3 phases 230V	CE44, CCQ9046, CCQ90663	0101505
3	415251	2500W/230V	-	0101564




Item	Order	Description	Model	OEM
1	375412	thermostat	SC46, SC46TOP, CCG60652/3, CCT6046,	0101384
2	550060	retainer	ET_, EQ_,	0101378
3	300080	switch	CCG7046/70663,	0101379
4	359291	signal lamp (green)	CCT7046/70663,	0101169
5	359290	signal lamp (yellow)	CCQ7046/70663	0101167



Item	Order	Description	Model	OEM
1	no longer available	knob	SC46, SC46TOP, CCG60652/3, CCT6046,	0101215
2	111517	knob	ET_, EQ_, CCG7046/70663,	0101789
3	110721	knob, S-shape	CCT7046/70663, CCQ7046/70663,	0101956
4	375017	safety thermostat	CE7_, CET7_, CE2_, CE4_, CE6_	0101375




Item	Order	Description	Model	OEM
1	300081	changer switch	CCG60652/3,	0101397
2	110722	knob	CCT6046,	0101955
3	111519	knob, S-shape	ET_, EQ_,	0101788
4	375017	safety thermostat	CCG9046/90663	0101375




Item	Order	Description	Model	OEM
1	375540	thermostat, 1-pole	CE7_, CET7_,	0101382
2	375412	thermostat, 3-pole	CE2_, CE4_,	0101384
3	359048	signal lamp	CE6_	0101170

## Hot cupboards (electric)



Item	Order	Description	Model	OEM
1	416827	1000W/230V	CCG6_, CCG7_, CCQ7_, CCT7_, CG7_	0101494
2	416828	1000W/230V	CV_, CCG9_	0101532



Item	Order	Description	Model	OEM
1	375275	safety thermostat	CCG6_, CCG7_	0101404
2	390040	thermostat	CCQ7_, CCT7_	0101403
3	300091	switch	CG7_	0109057



Item	Order	Description	Model	OEM
1	375537	safety thermostat	CCG6_, CCG7_	0101395
2	375539	thermostat	CCQ7_, CCT7_	0101396
3	300091	switch	CG7_	0109057



Item	Order	Description	Model	OEM
1	110724	knob	CCG6_, CCG7_	0101962
2	111520	knob, S-shape	CCQ7_, CCT7_	0101797
3	359291	signal lamp (green)	CG7_, CV_	0101169
4	359290	signal lamp (yellow)	CCG9_	0101167

## Fry tops (gas)



Item	Order	Description	Model	OEM
1	105255	burner	GRG654/8, CGG6020/40,	0109046
2	105260	burner	CG7_, CGG7020/21/40/41	0109045



Item	Order	Description	Model	OEM
1	105539	burner	FT721/41	0100270
2	105540	burner	FT20/21/40/41	0100269
3	105253	burner	CGG90_-1/3	0100284
4	105252	burner	CGG90_	0100295



Item	Order	Description	Model	OEM
1	101397	gas tap	CRG6_	0100731
2	101086	gas tap	CGG90_-0/2	0100732
3	101087	gas tap	FT721/741, FT2_, FT4_	0100733



Item	Order	Description	Model	OEM
1	111513	knob	CRG6_	0101204 0101954
2	111514	knob, S-shape		0101798
3	110729	knob	CGG90_, -0/2, FT721/741, FT2_, FT4_	0101211 0101965
4	111515	knob, S-shape		0101787



Item	Order	Description	Model	OEM
1	101076	thermostat		0100724
2	no longer available	knob	CRG6_/C, FT721/741	0101227
3	111522	knob, S-shape		0101785


S

Suitable for Silko







Item	Order	Description	Model	OEM
1	101125	Eurosit controller	CGG6__, CGG7__, CGG90__, CGG90-/C	0100873 KVL0001 KVL0004
1	101409	Eurosit controller	CGG6-/C, CGG7-/C, CGG90-1/3	0100879 KVL0007
2	110358	adapter	CGG6__, CGG7__,	-
3	110730	knob	CGG90__, CGG90-/C,	0101967
4	111523	knob, S-shape	CGG6-/C, CGG7-/C, CGG90-1/3	0101802



Item	Order	Description	Model	OEM
1	102040	thermocouple	universal	0100808
2	100050	pilot burner	CRG__, CRG_/C,	0109047
3	100701	electrode	CG7__, CGG7__, CGG7_/C	0100831
4	100003	piezoelectric igniter	CRG__, CRG_/C, CG7__	0100898
5	100009	piezoelectric igniter	CGG6__, CGG6_/C, CGG7__, CGG7_/C	0100895



Item	Order	Description	Model	OEM
1	100054	pilot burner	FT721/741, FT2__,	0100799
2	100701	electrode	FT4__	0100831
3	100199	ignition cable	FT721/740	0101631
4	100003	piezoelectric igniter		0100898




Item	Order	Description	Model	OEM
1	100010	ignition switches		0101184
2	101002	ignition unit	FT20/21, FT40/41	0101196
3	102155	ignition cable, 900mm		



Item	Order	Description	Model	OEM
1	100076	pilot burner		0101047
2	100701	electrode		0100831
3	102155	ignition cable, 900mm	CGG90__, CGG90_/C	9303074
4	100010	ignition switches		0101188
5	101012	ignition unit		0101193




Item	Order	Description	Model	OEM
1	100046	pilot burner		0100822
2	100706	electrode	CGG90__-1/3,	0100369
3	100019	ignition cable, 900mm	CGG90__0/2	9303461
4	100008	piezoelectric igniter		0100893




Item	Order	Description	Model	OEM
1	101265	thermocouple interrupter	CGG6_/C, CGG7_/C, CGG90__-1/3	0100835
2	375017	safety thermostat	CGG6_/C, CGG7_/C	0101401 0101375
3	375284	safety thermostat	CGG90__-1/3	0101425


## Fry tops (electric)



Item	Order	Description	Model	OEM
1	415651	1500W/230V	GR654/8, CGE60__, EG7__	0109041
2	415369	1350W/230V	FT7__	0101529
3	415296	1500W/230V	CGE70__	0101563



Item	Order	Description	Model	OEM
1	415250	1650W/230V	CGE90__	0101527
2	415253	2000W/230V	CGE90__ -0/1/2/3	0101521




Item	Order	Description	Model	OEM
1	375540	thermostat, 3-pole		0101382
2	375412	thermostat, 3-pole	GR654, GR658, FT_7__, CGE60__	0101384
3	300002	switch		0101398



Item	Order	Description	Model	OEM
1	375268	thermostat		0101373
2	550060	retainer	CGE/0	0101378
3	300002	switch		0101398



Item	Order	Description	Model	OEM
1	375270	thermostat		0101377
2	550060	retainer	CGE90__	0101378
3	300091	switch		0109057



Item	Order	Description	Model	OEM
1	375272	thermostat		0101424
2	550060	retainer	chromium-plated plate	0101378
3	300080	switch		0101379



Item	Order	Description	Model	OEM
1	110721	knob		0101207
			GR654/8, CGE60__, CG7__, CGE70__, CG90__, CG90__ -0/1/2/3	0101215 0101956 0101789
2	111517	knob, S-shape		0101789
3	359291	signal lamp (green)		0101169
4	359290	signal lamp (yellow)		0101167




Item	Order	Description	Model	OEM
1	300104	switch		0101400
2	110728	knob	FT7__, FT3__, FT5__	0101221 0101961
3	359292	signal lamp (red)		0101168

S

Suitable for Silko



**Chargrills (electric)**



Item	Order	Description	Model	OEM
1	375017	safety thermostat	GR654/8, LGE60__, EG7__ (from 1993), CGE70__ (1 series), CGE90__	0101375
1	375279	safety thermostat	CGE70__ (2 series)	0101372
1	375284	safety thermostat	CGE90__ -0/1/2/3	0101425
2	380263	contactor	CGE90__	0101330



Item	Order	Description	Model	OEM
1	415762	850W/230V		0101522
2	301003	switch, 2-pole	CRE6-20,	0109015
3	375332	safety thermostat, 55°C	CRE6-30	0101390
4	380263	contactor		0101330

**Lava rock grills (gas)**



Item	Order	Description	Model	OEM
1	105548	burner	CRG7022/42	0108191
2	105549	burner	CRG9022/42	0108175
3	102042	thermocouple	CRG__	0100809




Item	Order	Description	Model	OEM
1	380009	energy regulator		0108231
2	110720	knob	CRE6-20,	0101210
			CRE6-30	0101957
3	111516	knob, S-shape		0101790
4	359291	signal lamp (green)		0101169



Item	Order	Description	Model	OEM
1	101086	gas tap	CRG7022,	0108109
2	110729	knob	CRG7042,	0101965
3	111515	knob, S-shape	CRG9022,	0101787
			CRG9042	

**Bratt pans/boiling kettles (electrical)**



Item	Order	Description	Model	OEM
1	416829	3400W/230V		0108151
2	380015	energy regulator		0108203
3	110721	knob	CBE6030	0101936
				0101207
4	111517	knob, S-shape		0101789
5	359291	signal lamp		0101169



Item	Order	Description	Model	OEM
1	100051	pilot burner		0108109
2	100701	electrode	CRG7022,	0108194
			CRG7042,	
3	100019	ignition cable	CRG9022,	0108189
			CRG9042	
4	100009	piezoelectric igniter		0100895

S

Suitable for Silko


## Pasta cookers (gas)



Item	Order	Description	Model	OEM
1	105541	burner	CP70, CP770, NK742	0100278
2	105542	burner	NK741	0108100
3	105254	burner	CNG70130/230, CNG90130/140/230	0100296
4	105252	burner	CNG70166, CNG90160	0100295



Item	Order	Description	Model	OEM
1	101086	gas tap		0100732
2	110729	knob	CP70/770, NK721/742	0101965
3	111515	knob, S-shape		0101787



Item	Order	Description	Model	OEM
1	101397	gas tap	CNG70130,	0100731
2	111513	knob	CNG70230,	0101954
3	111514	knob, S-shape	CNG90130/130S, CNG90140/140S, CNG90230	0101798




Item	Order	Description	Model	OEM
1	101092	gas tap		0100736
2	110729	knob	CNG70160, CNG90160	0101965
3	111515	knob, S-shape		0101787



Item	Order	Description	Model	OEM
1	102042	thermocouple, M9x1, 850mm	CP__, NK__, CNG__130/160/230	0100809
1	102072	thermocouple, M10x1, 1000mm	CNG__160	0100811
2	100046	pilot burner	CP__, NK__, CNG__	0100822
3	100706	electrode		0100832
4	100003	piezoelectric igniter	CP__, NK__	0100898
5	100009	piezoelectric igniter	CNG__	0100895

## Pasta cookers (electric)



Item	Order	Description	Model	OEM
1	415902	2510W/230V	CP656, CNE6030	0109035
2	415295	1680W/230V	NK721E, CNE70__, CNE90__	0108111



Item	Order	Description	Model	OEM
1	300104	switch		0101400
2	110728	knob	CP656, CNE6030	0101961
3	111524	knob, S-shape		0101794
4	359291	signal lamp (green)		0101169



Item	Order	Description	Model	OEM
1	375021	thermostat		0108112
2	550060	retainer	NK721E, CNE70130	0101378
3	300078	switch		0108026


S

Suitable for Silko





Item	Order	Description	Model	OEM
1	375021	thermostat	CNE90130/130S,	0108112
2	550060	retainer	CNE90140/140S,	0101378
3	300002	switch	CNE90230	0101398



Item	Order	Description	Model	OEM
1	375277	safety thermostat	NK721E, CNE70130, CNE90130/140, CNE90230	0108113
1	375281	safety thermostat	CNE90160/160	0102493
2	375278	safety thermostat	CNE70160	0101394
3	380263	contactor	CNE70160, CNE90160	0101330



Item	Order	Description	Model	OEM
1	375341	thermostat		0102492
2	550060	retainer	CNE70160,	0101378
3	300080	switch	CNE90160/160S	0101379

Pasta cookers (mechanical)



Item	Order	Description	Model	OEM
1	540650	drain tap	CP656, CNE6030	0109012
2	540651	drain pipe		0109013
3	540652	drain tap	CP70/770, NK742	0100590



Item	Order	Description	Model	OEM
1	375054	thermostat		0101383
2	550060	retainer	CNE70160	0101378
3	300080	switch		0101379



Item	Order	Description	Model	OEM
1	540653	drain tap	NK721/721E	0108002
2	no longer available	lever		0108001
3	540655	drain tap	CN_70	0100605



Item	Order	Description	Model	OEM
1	110058	knob		0101219
2	111525	knob, S-shape	NK721, CNE70_	0101958
3	359291	signal lamp (green)	CNE90_	0101791
4	359290	signal lamp (yellow)		0101169
				0101167



Pos.	Order	Description	Model	OEM
1	540656	inlet tap	universal	0100540

S

Suitable for Silko



Item	Order	Description	Model	OEM
1	970206	basket	CP656, CNE6030	0109032
2	970204	basket, 1/3	NK_, CN_70_, CN_90_	0101122
3	970205	basket, 1/3	CN90140/140S	0101125

## Bains-marie (gas)



Item	Order	Description	Model	OEM
1	105255	burner	GB7	0109046
2	105543	burner	BM_	0100267
3	105257	burner	CMG_	0100280



Item	Order	Description	Model	OEM
1	101104	Babysit control switch	BM_, GB_	0100878
2	102042	thermocouple, 850mm	BM_	0100809
3	100054	pilot burner		0100799



Item	Order	Description	Model	OEM
1	102040	thermocouple, 500mm	GB_	0100808
2	100050	pilot burner		0109047
3	100701	ignition cap	BM_, GB_	0100830 0100831
4	100003	piezoelectric igniter		0100898



Item	Order	Description	Model	OEM
1	101413	Eurosit controller		0100880 KVL0008
2	102040	thermocouple, 500mm	CMG_	0100808
3	100076	pilot burner		0101047



Item	Order	Description	Model	OEM
1	100701	electrode	CMG_	0100831
2	100009	piezoelectric igniter	CMG70_	0100895
3	100008	piezoelectric igniter	CMG50	0100893

## Bains-marie (electric)




Item	Order	Description	Model	OEM
1	415130	1600W/230V	BM654/658, CME6020/40, CME7020	0109060
2	415844	2600W/230V	BM656, CME6030	0109061




Item	Order	Description	Model	OEM
1	415143	2000W/230V	BM_	0101530
1	415197	2000W/400V		0101531
2	415300	1350W/230V	CME7021/22, CME7041/42, EB_	0101492





Item	Order	Description	Model	OEM
1	375054	thermostat, 110°C	(until 1991) BMG__, EB__, BM7__, BM3__	0101383
1	390040	thermostat, 90°C	CME__, (from 1991) BMG__, EB__	0101403, 0101376
2	375143	thermostat, 110°C	BM7__, BM5__	0101388



Item	Order	Description	Model	OEM
1	100010	switch		0101188 0101184
2	370015	solenoid valve		0101341

**Bains-marie (mechanical)**




Item	Order	Description	Model	OEM
1	390040	thermostat		101403
2	550060	retainer	CME90__	0101378
3	300002	switch		0101398



no longer available  
3

Item	Order	Description	Model	OEM
1	540650	drain tap	BM6__, CME6__,	0109012
2	540651	drain pipe	CM_7020	0109013
3	no longer available	drain tap	EB__, BM2__, BM3__, BM4__, BM5__, BM7__	0100594




Item	Order	Description	Model	OEM
1	110058	knob, 110°C	BM6__, BM3__, EB__, BM7__	0101219 0101958
2	111525	knob, S-shape		0101791
3	110724	knob, 90°C	CME__, BMG__, EB__	0101806 0101962
4	111520	knob, S-shape		0101797



Item	Order	Description	Model	OEM
1	540658	drain tap	CM_7021/22,	0100593
2	540652	drain tap/inlet tap	CM_7041/42	

**Sausage cookers (electrical)**



Item	Order	Description	Model	OEM
1	301003	switch, 2-pole	BM6__, BM7__, EB__, CME6__, CME7__	0109015
2	375541	safety thermostat	CME90__	0101407
3	359291	signal lamp (green)	universal	0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	415130	1500W/230V		0109060
2	301003	switch	CCW6020	0109015
3	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	390040	thermostat		0101403
2	110724	knob		0101206 0101962
3	111520	knob, S-shape		0101797



Item	Order	Description	Model	OEM
1	390040	thermostat		0101403
2	110724	knob	CSP6020	0101806 0101962
3	111520	knob, S-shape		0101797

## Chip scuttles (electric)




Item	Order	Description	Model	OEM
1	416832	650W/230V		0109049
2	415103	650W/230V	CS654	0109051
2	415104	1000W/230V	CSP6020	0109050
3	301003	switch		0109015
4	359290	signal lamp (yellow)	CS654	0101167

## Fryers (gas)



Item	Order	Description	Model	OEM
1	105261	burner	FRG651/652, CFG60110/210	0109016
2	105544	burner	CFG70115 (left), CFG70215 (left), CFG90210, GF715/730	0108045
3	105545	burner	CFG70115 (right), CFG70215 (right), CFG90120/220	0108046



Item	Order	Description	Model	OEM
1	375054	thermostat, 110°C		0101383
2	110058	knob	CS654 (until 1993)	0101219 0101958
3	111525	knob, S-shape		0101791



Item	Order	Description	Model	OEM
1	105546	burner	FG712/24	0100273
2	105547	burner	FR-1G/2G	0100268



Item	Order	Description	Model	OEM
1	390040	thermostat, 90°C		0101376
2	110724	knob	CS654 (from 1993)	0101806 0101962
3	111520	knob, S-shape		0101797



Item	Order	Description	Model	OEM
1	101162	Novasit gas valve		0109010
2	101312	micro switch	FRG652, FRG654,	0109011
3	101313	coil, 230V	LFG60110/210	
4	101002	ignition unit		0101197


S

Suitable for Silko






Item	Order	Description	Model	OEM
1	100046	pilot burner		0100822
2	102042	thermocouple		0100809
3	101265	interrupter	FRG652 (until 1993), FRG653 (until 1993)	0100835
4	100706	electrode		0100832




Item	Order	Description	Model	OEM
1	101912	Minisit controller		0100871
2	102070	thermocouple	FG712/724, FR1G/2G	0100810 0100797
3	375166	safety thermostat		0101386



Item	Order	Description	Model	OEM
1	100145	pilot burner	FRG652 (from 1993), FRG653 (from 1993)	0109087 0100810
2	102069	thermocouple	CFG60110/210	0109027
3	100822	electrode		



Item	Order	Description	Model	OEM
1	100054	pilot burner (left)		0100799
2	100053	pilot burner (right)	FG712, FG714, FR1G/2G	0100800
3	100701	electrode		0100831
4	100026	ignition cable		0100858



Item	Order	Description	Model	OEM
1	301003	switch		0109015
2	375282	safety thermostat	FRG652, FRG654, LFG60110/210	0109053
3	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	101131	Minisit controller		0108030
2	102042	thermocouple	GF715/730, CFG70_	0100809 0100835
3	101265	interrupter	CFG90_	0100835
4	375376	safety thermostat		0108038




Item	Order	Description	Model	OEM
1	375271	thermostat		0109054
2	110725	knob	FRG652, FRG654, LFG60110/210	0101205 0101960
3	111526	knob, S-shape		0101793



Item	Order	Description	Model	OEM
1	100046	pilot burner	GF715/730,	0100822
2	100706	electrode	CFG70_	0100832
3	100026	ignition cable	CFG90_	0100858

## Fryers (electric)



Item	Order	Description	Model	OEM
1	415257	6300W/230V	FR651/652, CFE60110/210, CFE70110/0	0109025
2	416054	2000W/230V	FR651/5, FR65215, CFE60110/5, CFE60210/5	0109022
3	416055	3000W/230V	FRE51/9, FR652/9, CFE60110/9, CFE60210/9	0109021




Item	Order	Description	Model	OEM
1	415712	1800W/230V	FE712/724	0101499
2	415207	2185W/230V	EF710/720	0108020
3	416830	3670W/230V	EF715	0108021
4	no longer available	4750W/230V	EF716	0108022




Item	Order	Description	Model	OEM
1	415297	6800W/230V	CFE70110/110-2, CFE70210/210-2, EF710G/EF720G, CFE9210/210-2	0108058
2	416070	10200W/230V	CFE70115/115-2, CFE70215/215-2, EF715G	0108057
3	416059	1500W/230V	CFE90120/120-2, CFE90/220/220-2	0108064



Item	Order	Description	Model	OEM
1	510240	O-ring		0108055
2	510242	O-ring	CFE70_, CFE90, EF_G	0108056
3	550447	nut		0108054




Item	Order	Description	Model	OEM
1	375097	thermostat	FR_, CFE60110/210, CFE70110/0	0109055
2	300091	switch	FR651/652, CFE60110/210, CFE70110/0	0109057
3	345665	main switch	FR651-5/9, FR652-5/9, CFE60110-5/9, CFE60210-5/9	0109058



Item	Order	Description	Model	OEM
1	110725	knob	FR651-5/9, FR652-5/9, CFE60110-5/9, CFE60210-5/9, FR651/652, CFE60110/210, CFE70110/0	0101205 0101960
2	111526	knob, S-shape	FR651/652, CFE60110/210, CFE70110/0	0101793
3	110726	knob, O-I	FR651-5/9, FR652-5/9, CFE60110-5/9, CFE60210-5/9	0101208 0101959
4	111527	knob, S-shape	CFE60210-5/9	0101792



Item	Order	Description	Model	OEM
1	375063	thermostat		0101385
2	110725	knob	FE712, FE724, FR1E/2E, FE1E/2E	0101217 0101960
3	111526	knob, S-shape	FE1E/2E	0101793



Item	Order	Description	Model	OEM
1	375166	safety thermostat	FE712, FE724, FR1E/2E, FE1E/2E	0101386
2	380219	contactor		0101328


S

Suitable for Silko






Item	Order	Description	Model	OEM
1	300074	switch		0101380
2	110726	knob	FE712, FE724, FR1E/2E	0101213 0101959
3	111527	knob, S-shape		0101792




Item	Order	Description	Model	OEM
1	375261	thermostat		0108014
2	550060	retainer	EF710G/720G, CFE70110/210	0101378
3	300078	switch, 16A		0108026
4	300089	switch, 32A	CFE70110/-2, CFE70210/-2	0108074



Item	Order	Description	Model	OEM
1	375261	thermostat, 1-pole	EF71G,	0108014
2	300088	switch, 16A	CFE70115, LFG70215	0108007
3	346163	switch, 32A	EF716	0108008



Item	Order	Description	Model	OEM
1	110725	knob	EFEF710G/	0101960
2	111526	knob, S-shape	720G, CFE70, CFE90__	0101793
3	375258	safety thermostat	CFE70__, CFE90	0108065
4	375536	safety thermostat	EF710G/720G	0108061




Item	Order	Description	Model	OEM
1	110725	knob		0101225 0101217
2	111526	knob, S-shape	EF715/715G, EF716,	0101960
3	110726	knob, 0-I	CFE70115/115-2, CFE70215/215-2	0101213 0101959
4	111527	knob, S-shape		0101792

## Fryers (mechanical)



Item	Order	Description	Model	OEM
1	540650	drain tap	FRG651/2, FR651/2,	0109012
2	540651	drain pipe	CF_60110/210, CFE70110/0	0109013
3	540658	drain tap	FG712/14, FE712/14, FR1G/2G/1E/2E, FE1E/2E	0100593



Item	Order	Description	Model	OEM
1	375260	safety thermostat	EF716	0108011
2	375538	safety thermostat	EF715	0108025
3	375536	safety thermostat	EF715G	0108061
4	359291	signal lamp (green)	universal	0101169
5	359290	signal lamp (yellow)		0101167



no longer available

Item	Order	Description	Model	OEM
1	540653	drain tap	GF715/30, EF715/30	0108002
2	n. l. a.	lever		0108001






Pos.	Order	Description	Model	OEM
1	540638	drain tap	CF70110/110-2/210/210-2, CF70115/115-2/215/215-2, CF_90__	0108062



Item	Order	Description	Model	OEM
1	970217	basket	FRG651/652, FR651/652,	0109005
2	970218	batter filter	CFG60110/210, CFE600110-5/-9, CFE600210-5/-9	0109006
3	970215	basket	CFE60110/210,	0109089
4	970222	batter filter	CFE70110/0	0109092




Item	Order	Description	Model	OEM
1	970364	basket, 120x85x120mm	GF715/730, EF715/716, CFG70115/215,	0101098
2	970365	basket, 240x285x120mm	CFE70115/115-2, CFE70215/215-2	0101099

no longer available

no longer available

Item	Order	Description	Model	OEM
1	970366	basket	CF710G/720G	0101114
2	970367	basket	EF730G	0101116




Item	Order	Description	Model	OEM
1	970138	basket	CFE70110/110-2, CFE70210/210-2, CFG90110/210	0101100
2	970368	basket	CF90120/220	0101102


## Tilting bratt pans (gas)



Item	Order	Description	Model	OEM
1	105256	burner	BR7G, KF7G, CG70__	0100279
2	105543	burner	BR1G	0100267
3	105257	burner	CBG90__	0100280



Item	Order	Description	Model	OEM
1	101438	Minisit controller		0100855
2	101136	cover with Piezzo	BR7G, KF7G	0100857
3	110068	knob		0100856



Item	Order	Description	Model	OEM
1	101265	thermocouple interrupter		0100835
2	102040	thermocouple, 450mm	BR7G, KF7G	0100808
2	102042	thermocouple, 850mm		0100809
3	375285	safety thermostat		0101387

S


Suitable for Silko



Item	Order	Description	Model	OEM
1	100054	pilot burner	(until 1993) BR7G, KF7G	0100799
2	100701	electrode		0100831
3	100025	ignition cable		0100858




Item	Order	Description	Model	OEM
1	101127	Elettrosit gas valve	BR1G	0100883
2	102042	thermocouple		0100809
3	375285	safety thermostat		0101387



Item	Order	Description	Model	OEM
1	100076	pilot burner	(from 1993) KF7G	0101047
2	100701	electrode		0100831
3	100025	ignition cable		0100858




Item	Order	Description	Model	OEM
1	100054	pilot burner	BR1G	0100799
2	100701	electrode		0100831
3	101002	ignition unit		0101196



Item	Order	Description	Model	OEM
1	101125	Eurosit controller	CBG70, CBG9060/P, CBG9060C/P	KVL0006 0100873 KVL0003
2	102042	thermocouple		0100809
3	110730	knob		0101967
4	111523	knob, S-shape		0101802



Item	Order	Description	Model	OEM
1	375540	thermostat	BR1G	0101382
2	110721	knob		0101215 0101956
3	111517	knob, S-shape		0101789




Item	Order	Description	Model	OEM
1	300074	switch	BR1G	0101380
2	110726	knob		0101213 0101959
3	111527	knob, S-shape		0101792
4	359027	signal lamp (green)		0101171
5	359048	signal lamp (yellow)		0101170




Item	Order	Description	Model	OEM
1	100046	pilot burner	EBG70, CBG9060/P, CBG9060C/P	0100822
2	100706	electrode		0100832
3	100199	ignition cable		0109082
4	100009	piezoelectric igniter		0100895


## Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	101684	tandem valve		0102481
2	400172	ignition electrode	CBG9060C/I	0102479 63050060
3	541051	pressure switch		0102485




Item	Order	Description	Model	OEM
1	415298	3400W/230 V	BR7E, KF7E, CBE7050	0101526
2	415250	1650W/230 V	BR1E, CBE9060	0101527



Item	Order	Description	Model	OEM
1	375270	thermostat		0101377
2	550060	retainer	CBG9060C/I	0101378
3	300091	switch		-




Item	Order	Description	Model	OEM
1	375540	thermostat		0101382
2	550060	retainer	BR7E, KF7E	0101378
3	300080	switch		0101397




Item	Order	Description	Model	OEM
1	110727	knob		0101963
2	111528	knob, S-shape		0101799
3	359291	signal lamp (green)	CBG9060C/I	0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	110721	knob		0101215 0101956
2	111517	knob, S-shape	BR7E, KF7E	0101789
3	359291	signal lamp (green)		0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	375017	safety thermostat		0101375
2	346174	push button		0102474
3	345316	push button	CBG9060C/I	0102475
4	345349	limit switch		0101177



Item	Order	Description	Model	OEM
1	375285	safety thermostat		0101387
2	380263	contactor	BR7E, KF7E	0101330


S

Suitable for Silko






Item	Order	Description	Model	OEM
1	375270	thermostat		0101377
2	550060	retainer	CBE7050, CBE9060	0101378
3	300080	switch		0101379



Item	Order	Description	Model	OEM
1	300074	switch		0101380
2	110726	knob		0101959 0101213
3	111527	knob, S-shape	BR1E	0101792
4	359027	signal lamp (green)		0101171
5	359048	signal lamp (yellow)		0101170




Item	Order	Description	Model	OEM
1	110727	knob		0101963
2	111528	knob, S-shape	CBE7050,	0101799
3	359291	signal lamp (green)	CBE9060	0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	375285	safety thermostat	BR1E	0101387
2	380263	contactor		0101330

## Tilting bratt pans (mechanical)



Item	Order	Description	Model	OEM
1	375017	safety thermostat		0101375
2	380263	contactor	CBE7050, CBE9060	0101330
3	345349	micro switch		0101177



Item	Order	Description	Model	OEM
1	693125	nut		0100440
2	693126	shaft	KF7G/E, BR7G/E	0100453
3	690853	hand wheel		0100482
4	690855	hand wheel handle		0100483



Item	Order	Description	Model	OEM
1	375540	thermostat		0101382
2	110721	knob	BR1E	0101215 0101956
3	111517	knob, S-shape		0101789




Item	Order	Description	Model	OEM
1	693127	nut	CBG70_	LC333-04
2	693128	shaft	CBE70_	LC335-01
3	693113	hand wheel		LC336-00



Item	Order	Description	Model	OEM
1	693125	nut		0100440
2	693129	shaft	BR1G, BQ1E	0100436
3	690854	hand wheel		0100480
4	690856	hand wheel handle		0100481



Item	Order	Description	Model	OEM
1	101086	gas tap		0100732
2	110729	knob	CPD70_, CPI70	0101965
3	111515	knob, S-shape		0101787



Item	Order	Description	Model	OEM
1	102042	thermocouple, 850mm	CPD70	0100809
2	102070	thermocouple, 1000mm	CPI70	0100797
3	375281	safety thermostat		0102493



Item	Order	Description	Model	OEM
1	693127	nut		LC333-04
2	693128	shaft	CBG90_	LC335-01
3	693130	extension	CBE90_	9203699
4	690550	hand wheel		9203665



Item	Order	Description	Model	OEM
1	100046	pilot burner		0100822
2	100706	electrode	CPD70_, CPI70	0100369
3	100176	ignition cable		0101628
4	100009	piezoelectric igniter		0100895

## Boiling pans (gas)



Item	Order	Description	Model	OEM
1	105257	burner	CPD70_, CPD90_, CPI70_, CPI90_	0100280
2	105543	burner	PG10/15, PGB10	0100267



Item	Order	Description	Model	OEM
1	101093	gas tap		0100734
2	110729	knob	PG10/15, PG810	0101211 0101965
3	111515	knob, S-shape		0101787
4	102077	thermocouple		0100815





Item	Order	Description	Model	OEM
1	100044	pilot burner		0100821
2	100706	electrode		0100832




Item	Order	Description	Model	OEM
1	101684	tandem valve		0102481
2	400172	ignition electrode	CPD90__ CPI90__	0102479
3	541051	pressure switch		0102485



Item	Order	Description	Model	OEM
1	101092	gas tap		0100736
2	110729	knob	CPD90__/P, CPI90__/P	0101965
3	111515	knob, S-shape		0101787
4	102072	thermocouple	CPD90__/P	0100816



Item	Order	Description	Model	OEM
1	380009	energy regulator		0108231
2	550060	retainer	CPD90__ CPI90__	0101379
3	300091	switch		-




Item	Order	Description	Model	OEM
1	100046	pilot burner		0100822
2	100706	electrode	CPD90__/P, CPI90__/P	0100369
3	102164	ignition cable		93034515
4	100001	piezoelectric igniter		0102509



Item	Order	Description	Model	OEM
1	110720	knob		0101957
2	111516	knob, S-shape	CPD90__ CPI90__	0101790
3	359291	signal lamp (green)		0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	346174	push button/reset	CPD90__ CPI90__	0102474
2	359606	incandescent lamp		0102476




Item	Order	Description	Model	OEM
1	375281	safety thermostat		0102493
2	102070	thermocouple, 1000mm	CPI90__/P	0100797




Item	Order	Description	Model	OEM
1	400018	level regulator		0102477
2	400171	electrode	CPI90__	0102478
3	370332	solenoid valve		0102486



## Boiling pans (electric)




Item	Order	Description	Model	OEM
1	415299	6000W/3 phases 230 V	PEB750, CPE7-__	0101495
2	415256	7500W/3 phases 230 V	PEB10/15, CPE90100/150	0101493




no longer available

Item	Order	Description	Model	OEM
1	346172	switch	PEB750, CPE7-	0101392
2	n. l. a.	safety thermostat	PEB750	0101391
3	375281	safety thermostat	CPE7-__	0102493



Item	Order	Description	Model	OEM
1	375055	thermostat		0101383
2	110058	knob	PEB10, PEB15	0101219 0101958
3	111525	knob, S-shape		0101791



Item	Order	Description	Model	OEM
1	300074	switch		0101380
2	110726	knob		0101213 0101959
3	111527	knob, S-shape	PEB10, PEB15	0101792
4	359291	signal lamp (green)		0101169
5	359048	signal lamp (yellow)		0101170



Item	Order	Description	Model	OEM
1	375341	thermostat		0102492
2	550060	retainer	CPE90__	0101378
3	300091	switch		



Item	Order	Description	Model	OEM
1	111529	knob		0101964
2	111530	knob, S-shape	CPE90__	0102497
3	359291	signal lamp (green)		0101169
4	359290	signal lamp (yellow)		0101167



Item	Order	Description	Model	OEM
1	375281	safety thermostat		0102493
2	345562	contact block	CPE90__	0102506
3	345526	selector switch		0102505



Item	Order	Description	Model	OEM
1	400018	level regulator		0102477
2	400171	electrode	CPE90__	0102478
3	370332	solenoid valve		0102486

Suitable for Silko


Boiling pans (mechanical)



Item	Order	Description	Model	OEM
1	540131	drain cock, 1 1/4"	PG750, PGB750, PEB750	0100541
2	540276	drain cock, 1/2"	LPG70__, LBE70__	0100532
3	540275	drain cock, 2"	PG10/15, PGB10, PEB10/15, CPD90__	0100531



Item	Order	Description	Model	OEM
1	540836	filling funnel, 1 1/4"		0100575
2	540721	safety valve	PGB750, PEB750, CPE7-	0100589 0100587
3	540816	valve holder		0100571



Item	Order	Description	Model	OEM
1	540824	pressure relief valve	PGB750, PEB750,	0100568
2	540829	pressure gauge holder	CPE7-	0100579
3	541062	manometer		0100576



Item	Order	Description	Model	OEM
1	540823	safety valve, 3/4"	CPI70__	0102471
2	541334	manometer	CPI90__	0102491



Item	Order	Description	Model	OEM
1	540836	filling funnel	PGB10,	0100575
2	540721	safety valve	PEB10,	0100572
3	540821	valve holder	PEB15	0100578



Item	Order	Description	Model	OEM
1	541062	manometer	PGB10,	0100576
2	540830	pressure gauge tap	PEB10,	0100577
3	540829	holder	PEB15	0100579



Item	Order	Description	Model	OEM
1	540860	T-fittings	PGB10,	0100580
2	540827	pressure relief valve	PEB10, PEB15	0100573



Item	Order	Description	Model	OEM
1	540909	safety valve	PGB10,	0102494
2	540908	cover lock	PEB10, PEB15	0100585
3	540907	mixer tap	universal	0100525







