




Spare parts suitable for:
COMENDA



G.E.V. Großküchen-Ersatzteil-Vertrieb GmbH
Robert-Koch-Straße 3a
82152 Planegg/Munich
Germany

Phone: +49 (0)89 745572-0
Fax: +49 (0)89 745572-83
order@gev-online.com
www.gev-online.com

Member of the  **GEV GROUP**



Wash and rinse systems

Page 3



Various and air traps

Page 11



Drain and filter systems

Page 13




Door and hood components

Page 19



Electrical components

Page 21



Dosing pumps

Page 31



Heating elements and boilers


Page 32



Pumps and components

Page 34

Wash and rinse systems



Item	Order	Description	Model	OEM
1	510728	wash arm fixed	B10, B11, B12,	170603
2	510877	gasket	B10T, B11T, B12T,	200415
3	510731	end cap	B20, B20D, B23,	160710
4	511200	nut	B24, B25, B246, BR20, BR20A, BR25, BR25A, LBR200, LBR215, LBR215A	270106



Item	Order	Description	Model	OEM
1	510739	rinse arm upper		170621
2	510279	rinse arm lower		170622
3	510740	gasket	B20, B20D, B24, B25, B26, B27	200458
4	510303	O-ring		200818
5	510309	rinse jet		170911
6	510310	rinse jet holder		170704




Item	Order	Description	Model	OEM
1	510732	column	B10, B10T, B20, B20D, BR20, BR20A	170618
2	510280	column	B11, B12, B11T, B12T, B23, B24, B25, B26, B27, BR25, BR25A, LBR200, LBR215, LBR215A	170604
3	510733	gasket	B10, B11, B12, B10T,	200819
4	510734	wash jet	B11T, B12T, B20, B20D, B23, B24,	170924
5	510735	wash jet inner	B25, B26, B27, BR20,	190618
6	510736	wash jet outer	BR20A, BR25, BR25A, LBR200, LBR215, LBR215A	170908



Item	Order	Description	Model	OEM
1	510742	rinse arm compl.	B_T	380604
2	510335	rinse jet		380309



Item	Order	Description	Model	OEM
1	510743	rinse arm compl.		331344
2	510309	rinse jet	B23-B27	170911
3	510310	rinse jet holder		170704



Item	Order	Description	Model	OEM
1	510737	rinse arm upper		170636
2	510738	rinse arm lower		170635
3	510885	gasket	B10, B11, B12, B10T, B11T,	200464
4	510902	O-ring	B12T, BR__,	200844
5	510327	rinse jet	BR_A, LBR__,	170946
6	510903	O-ring	LBR_A	200845
7	512097	end cap		160734



Item	Order	Description	Model	OEM
1	510262	wash and rinse arm lower compl.	B_T, B_TM,	420531
2	510325	wash jet	BC__, BC_A,	170956
3	510901	O-ring	BHC__, BHC_A,	200843
4	510327	rinse jet	BHC_HR,	170946
5	510902	O-ring	BHC_HRA,	200844
6	510321	end cap large	LBC__, LBC_ _A, F20*,	160736
7	510322	O-ring	FC43	200812
8	510323	end cap small		160734
9	510903	O-ring	*also upper	200845
10	510329	bearing bush		190624

Suitable for Comenda



Item	Order	Description	Model	OEM
1	510261	wash and rinse arm lower compl.		420516
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap		160719
6	510302	O-ring		200824
7	510309	rinse jet	B_T, B_TM,	170911
8	510310	rinse jet holder	B41*, B42*, F20*	170704
9	510301	end cap	* (also upper)	160718
10	510303	O-ring		200818
11	510871	wash arm cross		191022
12	510314	wash jet		170927
13	510315	rinse jet		170929
14	510316	blind jet large		170928
15	510317	blind jet small		170930
16	510313	bearing bush		190617




Item	Order	Description	Model	OEM
1	510268	wash and rinse arm upper compl.		420538
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap		160719
6	510302	O-ring		200824
7	510309	rinse jet		170911
8	510310	rinse jet holder	B_TM	170704
9	510301	end cap		160718
10	510303	O-ring		200818
11	510748	wash arm cross		191055
12	510314	wash jet		170927
13	510315	rinse jet		170929
14	510316	blind jet large		170928
15	510317	blind jet small		170930
16	510313	bearing bush		190617



Item	Order	Description	Model	OEM
1	510741	wash and rinse arm upper compl.		420533
2	510325	wash jet		170956
3	510901	O-ring		200843
4	510327	rinse jet		170946
5	510902	O-ring	B_TM	200844
6	510321	end cap large		160736
7	510322	O-ring		200812
8	510323	end cap small		160734
9	510903	O-ring		200845
10	510329	bearing bush		190624



Item	Order	Description	Model	OEM
1	510744	wash and rinse arm upper compl.		420551
2	510325	wash jet		170956
3	510901	O-ring	BC_, BC_A,	200843
4	510327	rinse jet	BHC_,	170946
5	510902	O-ring	BHC_A,	200844
6	510321	end cap large	BHC_HR,	160736
7	510322	O-ring	BHC_HRA,	200812
8	510323	end cap small	LBC215,	160734
9	510903	O-ring	LBC215A,	200845
10	510329	bearing bush	LBC275,	190649
			LBC275A,	190624
			FC43	



Item	Order	Description	Model	OEM
1	510746	rinse arm compl.		430326
2	510327	rinse jet		170946
3	510902	O-ring	LBC210	200844
4	510323	end cap		160734
5	510903	O-ring		200845
6	510329	bearing bush		190649



Item	Order	Description	Model	OEM
1	510749	wash and rinse arm compl.		420546
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap		160719
6	510302	O-ring		200824
7	510309	rinse jet		170911
8	510310	rinse jet holder	BC_HR	170704
9	510301	end cap	BC_HRA	160718
10	510303	O-ring		200818
11	510748	wash arm cross		191055
12	510314	wash jet		170927
13	510315	rinse jet		170929
14	510316	blind jet large		170928
15	510317	blind jet small		170930
16	510313	bearing bush		190617



Item	Order	Description	Model	OEM
1	510747	wash and rinse arm lower compl.		420545
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap		160719
6	510302	O-ring		200824
7	510309	rinse jet	BC_HR,	170911
8	510310	rinse jet holder	BC_HRA	170704
9	510301	end cap		160718
10	510303	O-ring		200818
11	510748	wash arm cross		191055
12	510314	wash jet		170927
13	510315	rinse jet		170929
14	510316	blind jet large		170928
15	510317	blind jet small		170930
16	510313	bearing bush		190617



Item	Order	Description	Model	OEM
1	510275	wash and rinse arm compl.		420526
2	510325	wash jet	F45, F55, F65, F85,	170956
3	510901	O-ring	LF280Lavline,	200843
4	510327	rinse jet	LV315, LF320,	
5	510902	O-ring	LF320Lavline,	170946
6	510321	end cap large	LF320A,	200844
7	510322	O-ring	LF320CBT,	160736
8	510323	end cap small	LV320LA,	
9	510903	O-ring	LF320LBT, LF323,	200812
10	510329	bearing bush	LF323A, LF350,	160734
			LF350A, LP360,	200845
			LP360BT	190624

Suitable for Comenda



Item	Order	Description	Model	OEM
1	510260	wash and rinse arm compl.		420515
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap		160719
6	510302	O-ring		200824
7	510309	rinse jet	F2, F3, F300, F45, F55, F65, F85,	170911
8	510310	rinse jet holder	C30, C70, C75, C85, C75BT	170704
9	510301	end cap		160718
10	510303	O-ring		200818
11	510314	wash jet		170927
12	510315	rinse jet		170929
13	510316	blind jet large		170928
14	510317	blind jet small		170930
15	510313	bearing bush		190617




Item	Order	Description	Model	OEM
1	510271	wash arm compl.		420511
2	510353	wash jet		170918
3	510305	wash jet holder	C33, C34, C140,	180213
4	510300	end cap	LC380 (to 4/98),	160719
5	510302	O-ring	LC38BT (to 4/98),	200824
6	510849	wash arm center	LC400 (to 4/98)	191027
7	510316	blind jet large		170928
8	510314	wash jet		170927
9	510312	bearing bush		190621



Item	Order	Description	Model	OEM
1	510272	rinse arm compl.		430308
2	510309	rinse jet		170911
3	510310	rinse jet holder		170704
4	510301	end cap	C33, C34, C140,	160718
5	510303	O-ring	LC140, LC380,	200818
6	510872	rinse arm boss	LC380BT, LC400	191030
7	510315	rinse jet		170929
8	510317	blind jet		170930
9	510303	O-ring		200818
10	510313	bearing bush		190617



Item	Order	Description	Model	OEM
1	510270	wash and rinse arm compl.		420510
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510305	wash jet holder		180213
5	510300	end cap	F2 (first series)	160719
6	510302	O-ring	F3 (first series)	200824
7	510309	rinse jet	F300 (first series)	170911
8	510310	rinse jet holder	C30 (first series)	170704
9	510301	end cap		160718
10	510303	O-ring		200818
11	510308	bearing bush		190615



Item	Order	Description	Model	OEM
1	510750	wash and rinse arm compl.		420522
2	510304	wash jet right		170915
3	510306	wash jet left		170916
4	510752	wash jet right		170923
5	510753	wash jet left	C75M, LF400A,	170922
6	510305	wash jet holder	LF450, LF450A,	180213
7	510300	end cap	F90M, F90MA	160719
8	510302	O-ring		200824
9	511230	rinse jet		170941
10	510310	rinse jet holder		170704
11	510301	end cap		160718
12	510303	O-ring		200818




Item	Order	Description	Model	OEM
1	510871	wash arm cross		191022
2	510314	wash jet		170927
3	510316	blind jet large		170928
4	510303	O-ring	C75M, LF400A, LF450, LF450A,	200818
5	510315	rinse jet	F90M, F90MA	170929
6	510317	blind jet small		170930
7	510303	O-ring		200818
8	510313	bearing bush		190617



Item	Order	Description	Model	OEM
1	510741	wash and rinse arm compl.	LC380 (from 4/98),	420553
2	511240	bush	LC380BT (from 4/98),	191076
3	511241	nut	LC400 (from 4/98)	191075



Item	Order	Description	Model	OEM
1	510259	wash arm compl.		420548
2	510313	bearing bush		190617
3	511007	wash arm support	FC_, FC_A,	191070
4	511231	wash arm support	FC_E, FC_EA,	191069
5	511233	rinse arm lower	FC_CBT,	430332
6	511234	rinse arm spindle	FC_LBT,	342706
7	511235	bearing bush	FC_HR,	190663
8	511009	lock nut	FC_HRA, C75,	280413
9	511236	rinse jet	C75BT	170963
10	511237	O-ring		200850
11	511238	spring clip		450236



Item	Order	Description	Model	OEM
1	510265	wash arm	C95, C95E2, C95BT	420540
2	510264	wash arm	C155, C155E2, C155BT, C165, C165E2, C165BT, C166, C166-2	420535
3	510823	bearing bush	C95, C95E2, C95BT,	190636
4	510825	end cap	C155, C155E2, C155BT,	160768
5	511191	O-ring	C165, C165E2, C165BT, C166, C166-2	200813



Item	Order	Description	Model	OEM
1	510266	rinse arm		430316
2	510346	lock nut	C95, C95E2, C95BT,	280409
3	510813	bearing bush	C155, C155E2, C155BT,	190641
4	511242	clamp spring	C165, C165E2, C165BT,	450218
5	510369	rinse jet	C166, C166-2	380314
6	511018	O-ring		200809



Item	Order	Description	Model	OEM
1	511011	rinse arm spindle		342051
2	511010	bearing bush	FC_to	190652
3	511009	lock nut	No. 11091 (10/98),	280413
4	511012	rinse jet	C75, C75BT	170958
5	510903	O-ring		200845
6	511011	rinse arm spindle		342051
7	511239	bearing bush	FC_from	190656
8	511009	lock nut	Nr.11092 (10/98)	280413
9	510369	rinse jet	to (4/00),	380314
10	511018	O-ring	C75, C75BT	200809

Suitable for Comenda



Item	Order	Description	Model	OEM
1	511243	wash arm		420542
2	510823	bearing bush		190636
3	510825	end cap		160768
4	511191	O-ring		200813
5	510346	lock nut		280409
6	512209	rinse arm	GF90, GF90A	H35404
7	512210	rinse arm spindle		H34997
8	512211	bearing bush		H34383
9	512212	lock nut		H34998
10	510309	rinse jet		170911
11	510310	rinse jet holder		170704
12	510303	O-ring		200818



Item	Order	Description	Model	OEM
1	511247	wash arm		420544
2	511248	circlip Ø48mm		440816
3	511249	friction ring		160820
4	511250	rinse arm	G50LM, G65L, G75L, G115L, G125L	430323
5	510307	lock screw		261009
6	511245	bearing bush		190642
7	511242	clamp spring		450218
8	511246	rinse jet 1/8"		380333
9	510955	O-ring		200854




Item	Order	Description	Model	OEM
1	511243	wash arm		420542
2	510823	bearing bush		190636
3	510825	end cap		160768
4	511191	O-ring		200813
5	511244	rinse arm	G50L, G51L, G60L, G61L, G100L, G101L	430321
6	510307	lock screw		261009
7	511245	bearing bush		190642
8	511242	clamp spring		450218
9	511246	rinse jet 1/8"		380333
10	510955	O-ring		200854



Item	Order	Description	Model	OEM
1	511251	wash arm compl.		420505
2	511248	circlip		440816
3	511252	lock nut	G65, G66, G75, G115, G125, G131	510284
4	511249	friction ring		160820
5	510351	wash jet		170910
6	511253	wash jet holder		180211



Item	Order	Description	Model	OEM
1	510267	rinse arm		430306
2	510307	lock screw		261009
3	510940	bearing bush		190613
4	510369	rinse jet	G65, G66, G75, G115, G125, G131	380314
5	510334	rinse jet holder		170926
6	510305	support		180213
7	510302	O-ring		200824
8	510330	end cap		160754



Item	Order	Description	Model	OEM
1	510449	throttle disc	B__T, B__TM, B41, B42,	260539
2	510320	wash arm support lower	LBC, LBC__A, F20, F45,	191025
3	510447	O-ring 81,92x92,58x5,33	F55, F65, LF__ (from 9/01), LF__A (from 9/01),	200829
4	510408	O-ring 46,99x57,6x5,33	LF__L__ (from 9/01), LF__CBT (from 9/01), F2, F300, LF400A (from 9/01), LF450 (from 9/01), LF450A (from 9/01), F90M (from 9/01), F90MA (from 9/01),	200820




Item	Order	Description	Model	OEM
1	510863	support holder lower		190208
2	510892	O-ring 13,10x18,34x2,62	B__T, B__TM	200806
3	510408	O-ring 46,99x57,6x5,33		200820
4	510860	support holder lower	B41, B42, F20, F45, F55,	190203
5	510892	O-ring 13,10x18,34x2,62	F65, LF__, LF__A, LF__LBT__, LF__LA, LF__CBT, FC__, F2, F3, F300, C70, C75, C75BT, C75M, LP360, LP360BT, LF400A, LF450, LF450H, F90M, F90MA	200806
6	510408	O-ring 46,99x57,6x5,33		200820



Item	Order	Description	Model	OEM
1	510460	wash arm support lower	BC__, BC__A, BC__HR, BC__HRA,	191064
2	510970	O-ring 82,22x87,46x2,62	LF__ (to 9/01), LF__A (to 9/01), LF__L__ (to 9/01), LF__CBT (to 9/01), LF400 (to 9/01), LF450 (to 9/01), LF450A (to 9/01)	200856
3	510971	O-ring	FC43, FC43A F90M (to 9/01), F90MA (to 9/01),	200855
4	510461	support holder		190210
5	510892	O-ring 13,10x18,34x2,62	BC__, BC__A, BC__HR, BC__HRA, LBC__,	200806
6	510408	O-ring 46,99x57,6x5,33	LBC__A, FC43, FC43A	200820




Item	Order	Description	Model	OEM
1	511255	rinse arm holder		280529
2	510355	gasket	LBC210	460501
3	511232	rinse arm spindle		342056



Item	Order	Description	Model	OEM
1	511256	wash arm support lower	BHC__, BHC__A,	191083
2	511257	support holder	BHC__S, BHC__HR, BHC__HRA	190223
3	510448	wash arm support upper	B__TM, BC__, BC__A,	190209
4	510408	O-ring 46,99x57,6x5,33	BC__HR, BC__HRAC__, BHC__, BHC__A, BHC__S, BHC__HR, BHC__HRA, FC43, FC43A	200820




Item	Order	Description	Model	OEM
1	510861	wash arm support upper	F20, F45, F55, F65, F85,	190205
2	510408	O-ring 46,99x57,6x5,33	LF__LF__A, LF__LBT, LF__CBT, LF__A, F2, F3, F300	200820
3	510873	wash arm support lower		191031
4	510447	O-ring 81,92x92,58x5,33	F80, F3, C70, C75 (to 10/95), C75M,	200829
5	510408	O-ring 46,99x57,6x5,33	LP360, LP360BT	200820



Item	Order	Description	Model	OEM
1	511073	wash arm support lower	FC__, FC__A, FC__CBT,	191068
2	510447	O-ring	FC__LBT, FC__HR,	200829
3	510408	O-ring	FC__HRA	200820
4	511258	wash arm support lower		191077
5	510447	O-ring		200829
6	510408	O-ring	FC__E, FC__EA	200820
7	510302	O-ring		200824
8	510892	O-ring		200806



Item	Order	Description	Model	OEM
1	510408	O-ring	FC_, FC_A, FC_CBT, FC_E, FC_EA	200820
2	510860	support holder	FC_LBT, FC_HR, FC_HRA	190203
3	511179	wash arm support upper	FC_, FC_A, FC_CBT, FC_LBT, FC_HR, FC_HRA	190215
4	511259	wash arm support upper	FC_E, FC_EA	190218
5	510408	O-ring	FC_, FC_A, FC_CBT, FC_E, FC_EA	200820
6	511260	spraying protection	FC_LBT, FC_HR, FC_HRA	320161



Item	Order	Description	Model	OEM
1	511265	wash arm support lower	C75 (from 10/ 95), C75BT	191071
2	510447	O-ring		200829
3	510408	O-ring	C75 (from 10/ 95), C75BT	200820
4	511266	wash arm support upper		190216



Item	Order	Description	Model	OEM
1	510489	rinse arm spindle	F2, F3, F300, C30*	340468
2	510471	wash arm support lower	*(also upper)	510265
3	511261	wash arm holderrohr	F2, F3, F300	420307/C
3	511262	wash arm holderrohr	C30	420310/C



Item	Order	Description	Model	OEM
1	510318	rinse arm spindle upper		340499
2	510463	flange	C95, C95E2, C95BT, C155, C155E2, C155BT, C165, C165E2, C165E2BT, C166, C166-2	180240
3	510972	gasket		200909
4	510974	O-ring		200852
5	511267	O-ring		200853
6	510462	wash arm support lower		191059



Item	Order	Description	Model	OEM
1	510470	wash arm support upper		510201
2	510975	gasket	F2, F3, F300	200421
3	n. l. a.	flange		330904



Item	Order	Description	Model	OEM
1	510318	rinse arm spindle		340499
2	511268	wash arm support upper	LC380, LC380BT,	510503
3	510319	wash arm support lower	LC400	510238
4	511158	gasket		200482




Item	Order	Description	Model	OEM
1	510318	rinse arm spindle	C33, C34, C140	340499
2	510319	wash arm support		510238
3	510862	wash arm support upper	C70, C75M, C58,	190206
4	511264	wash arm support	C75, (to 10/95),	420310
5	510949	gasket	LP360, LP360BT	200483



Item	Order	Description	Model	OEM
1	n. l. a.	wash arm support upper	GF90, GF90A	H34444
2	510319	wash arm support lower	GF90, GF90A, G50L, G51L, G60L, G61L, G100L, G101L	510238
3	511269	wash arm support lower	G50LM, G65L, G75L,	341736
4	511270	rinse arm spindle	G115L, G125L	341912



Item	Order	Description	Model	OEM
1	511271	wash arm support	G	510280
2	511272	rinse arm spindle		340489




Item	Order	Description	Model	OEM
1	511278	hose connector		280509
2	510954	tube connector 3/8"/ 10 mm		190309
3	510481	elbow 5/8"/ 13mm		190315

Various



Item	Order	Description	Model	OEM
1	510842	T-fitting 13mm		180403
2	510983	T-fitting 11mm		180413
3	511273	cross fitting		191026



Item	Order	Description	Model	OEM
1	510912	elbow 3/8"/ 12mm		290217
2	510984	T-fitting		190311
3	511279	hose connector		290407



Item	Order	Description	Model	OEM
1	510843	T-fitting 11/7mm		180408
2	510933	T-fitting 11/ 1/4"		180411
3	510910	T-fitting		280306



Item	Order	Description	Model	OEM
1	510464	elbow connector 3/8"-14"		280118
2	511280	hose connector 1/2"/-13		290410

Hose clamps



Item	Order	Pack Qty	Size mm	OEM	Item	Order	Pack Qty	Size mm	OEM
1	520111	10	10-16	450102	6	520116	5	32-50	450107
2	520112	10	12-20	450103	7	520117	5	40-60	450135
3	520113	10	16-25	450104	8	520118	5	50-70	450109
4	520114	10	20-32	450114	9	520119	5	60-80	450119
5	520115	5	25-40	450105					




Item	Order	Description	Model	OEM
1	511274	divider		180415
2	511275	T-fitting drain pump		180416
3	510816	exhaust elbow		180308
4	511276	exhaust nut		260425
5	510886	gasket		200467


Rinse aid tanks




Item	Order	Description	Model	OEM
1	510857	container support	B10-B12	190117
2	510854	container		190809




Item	Order	Description	Model	OEM
1	510836	dirt filter		620209
2	510993	back flow restrictor		620243
3	510996	gasket		460502
4	510995	inlet part		290122
5	511277	T-fitting		190330



Item	Order	Description	Model	OEM
1	510855	container support		190106
2	510977	rod		340484
3	510978	clamp spring	B20-B42, B__T, B__TM, BHC__	450812
4	510853	container		190802
5	510479	lid		160715



Item	Order	Description	Model	OEM
1	510979	cover		321156
2	510977	rod		340484
3	510978	clamp spring	BC__, BR__, FC43, FC43A	450812
4	510480	container		190811
5	510479	lid		160715



Item	Order	Description	Model	OEM
1	510958	container support		190130
2	510874	container framework		191047
3	510980	bracket for frame	F20-F80	331439
4	510854	container		190809




Item	Order	Description	Model	OEM
1	n. l. a.	container		190804
2	n. l. a.	angle right	C30, C33, C34	350745
3	n. l. a.	angle left		350746



Item	Order	Description	Model	OEM
1	511394	cap		160784
2	511395	gasket	BHC	200868
3	511396	nut		160787




Item	Order	Description	Model	OEM
1	510349	cap compl.	BC__, BR__	160755
2	510947	gasket		200489



Item	Order	Description	Model	OEM
1	504045	salt container 90 mm		631304
2	510929	salt container 117mm		631302



Item	Order	Description	Model	OEM
1	524177	cap		
2	510898	gasket		200822
3	524178	nut		
4	510883	gasket		200454



Item	Order	Description	Model	OEM
1	530000	softener		640209
2	530019	softener		640212

Air traps



Item	Order	Description	Model	OEM
1	510347	air trap	B_, B_T, LBR_, LBR_A, LBC_, LBC_A, C85, C140, LC380, LC380BT, LC400, GF90, GF90A,	161303
2	510342	air trap	F2, F3, F300, C30, C33, C34, G_, G_L, G_LM	161301
3	510877	gasket		200415
4	511188	nut		260407



Item	Order	Description	Model	OEM
1	511199	air trap	C95, C95E2, C95BT,	161308
2	511283	gasket	C155, C155E2, C155BT,	200927
3	511284	nut	C165, C165E2,	270121
4	511289	hose	C165E2BT, C166,	161312
5	511286	clamp	C166-2	450143



Item	Order	Description	Model	OEM
1	511282	air trap		161310
2	511283	gasket	BC_, BC_A, BC_HR,	200927
3	511284	nut	BC_HRA, BR_,	270121
4	511285	hose	BR_A, FC43, FC43A	161311
5	511286	clamp		450143

Drain and filter systems



Item	Order	Description	Model	OEM
1	510444	drain plug	B10_B27,	180704 180702
2	510841	filter	B10T_B12T, LBR_,	180809
3	511290	gasket	LBR_A, LBC_,	200436
4	511291	drain sump	LBC_A	180210



Item	Order	Description	Model	OEM
1	510759	air trap		161316
2	510761	gasket	BHC_, BHC_A,	200944
3	511287	O-ring	BHC_S	200805
4	510760	hose connector		161317



Item	Order	Description	Model	OEM
1	510441	drain plug	B13T_B19T, B_TM, B41,	170707
2	510887	V-ring	B42, F2, F3, F300, F20, F45,	200469
3	510850	filter	F55, F65, LF280Lavline,	180808
4	510896	gasket	LF320Lavline, C30, LF400A	200828



Item	Order	Description	Model	OEM
1	510348	air trap	FC_, FC_A, FC_CBT,	161305
2	510486	air trap connection	FC_LBT, FC_E,	161306
3	510877	gasket	FC_EA, FC_HR,	200415
4	510354	nut 1/2"	FC_HRA, FC_HRT, FC_HRTA, F55, F65, F80, LF_, LF_A, LF_CBT, LF_LA, LF_LBT, F90M, F90MA, C70, C75BT, C75 M, LB300, LB360, LP360BT	160727




Item	Order	Description	Model	OEM
1	510442	drain plug		170708
2	510887	V-ring	F80, C70, C75, C75BT,	200469
3	510850	filter	C75M, LP360, LP360BT	180808
4	510896	gasket		200828




Item	Order	Description	Model	OEM
1	511292	drain plug	LF315, LF320, LF320A,	170710
2	510887	V-ring	LF320CBT, LF320LA,	200469
3	510850	filter	LF320LBT, LF323,	180808
4	510896	O-ring	LF323A, LF350,	200828
			LF350A, LF450,	
			LF450A, F90, F90A	



Item	Order	Description	Model	OEM
1	510985	drain plug	C30, C33, C34	180703
2	515046	drain plug	C85, C140, LC380,	180708
			LC380BT, LC400	
3	512214	drain plug	GF90, GF90A	H34431




Item	Order	Description	Model	OEM
1	510852	filter	B13T, B19T, B__TM,	180814
2	511293	sump	B41, B42, C70, C75,	180218
			C75BT, C75M, F2, F3,	
3	510303	gasket	F300, F20, F45, F55,	200818
			F65, F80, F90, F90A	
4	511278	tube connector	LF280Lavline,	280509
			LF320Lavline, C30,	
			LF400A, LP360,	
			LP360BT, LF315,	
			LF320, LF320A,	
			LF320CBT, LF323,	
			LF323A, LF350,	
			LF350A, LF450,	
			LF450A	



Item	Order	Description	Model	OEM
1	510805	drain connector	C30, C33, C34	160301
2	510875	gasket	C85, C140, LC380,	200410
			LC380BT, LC400	
3	510498	nut	GF90, GF90A	180109



Item	Order	Description	Model	OEM
1	510476	drain plug	C95, C95E2, C95BT,	180715
2	510887	gasket	C155, C155E2,	200469
3	510805	drain seating	C155BT, C165,	160306, 160301
4	510875	gasket	C165E2, C165E2BT,	200410
5	510498	nut	C166, C166-2	180109



Item	Order	Description	Model	OEM
1	510876	gasket	B10-B13, B41, B42,	200412
2	510356	nut	B__T, B__TM, F2, F3,	180102
			F300, F20, F45, F55,	
			F65, F80, LF__, LF__A,	
			C30, C33, C34, C70,	
			C75, C75BT, C85, C140,	
			C380, LC380BT, LC400	
3	511430	drain elbow	B10-B13	160204
4	510803	drain elbow	B__T, B__TM, F20, F45,	160203
			F55, F65, F80, LF__,	
			LF__A, C70, C75,	
			C75BT, C85, C140,	
			LP360, LP360BT,	
			LC380, LC380BT,	
			LC400, F90, F90A,	
			GF90, GF90A	
5	510807	drain elbow	B41-B42, F2, F3, F300,	160202
			C30, C33, C34	



Item	Order	Description	Model	OEM
1	510876	gasket	C95, C95E2, C95BT,	200412
2	511298	hose connector	C155, C155E2, C155BT,	160201
			C165, C165E2,	
3	510356	nut	C165E2BT, C166,	180102
			C0166-2	



Item	Order	Description	Model	OEM
1	511299	drain plug	G_L, G_LM,	380825
2	511306	drain plug	G65, G66, G115, G131,	380806
3	511307	drain plug	G75, G125	380823




Item	Order	Description	Model	OEM
1	511320	drain plug	BHC_, BHC_A,	180724
2	511321	cap	BHC_S,	180725
3	511322	gasket	BHC_HR,	200869
4	511323	spring	BHC_HRA	450232



Item	Order	Description	Model	OEM
1	511308	drain seating (steel)		270408
1	511431	drain seating (brass)		270403
2	510875	gasket	G_, G_L, G_LM	200410
3	511309	nut		270104
4	510876	gasket		200412
5	511298	hose connector		160201
6	510356	nut		180102




Item	Order	Description	Model	OEM
1	511324	filter	BHC_, BHC_A,	180824
2	511325	filter	BHC_S	332029
3	511326	filter	BHC_HR,	180828
4	511327	deflector	BHC_HRA	320166




Item	Order	Description	Model	OEM
1	510473	drain plug		180716
2	510976	V-ring	BC_, BC_A, BR_, BR_A, FC43, FC43A	200917
3	510474	filter		180817
4	510376	spring		450223




Item	Order	Description	Model	OEM
1	512109	drain seating		180147
2	512111	gasket		200867
3	511328	drain elbow	BHC_, BHC_A, BHC_S	190225
4	511329	outflow fitting	BHC_HR, BHC_HRA	180142



Item	Order	Description	Model	OEM
1	510475	flat filter	BC_, BC_A, BR_, BRA, FC43, FC43A	330591
2	511316	flat filter	BC_HR, BC_HRD	330597



Item	Order	Description	Model	OEM
1	511330	drain fitting		160310
2	511331	gasket		200842
3	511332	nut		180145



Item	Order	Description	Model	OEM
1	511317	drain seating		160771
2	511318	gasket		200913
3	511319	outflow-inlet fitting		180239



Item	Order	Description	Model	OEM
1	510835	drain plug	FC_, FC_A, FC_CBT,	170711
2	510887	V-ring	FC_LBT, FC_E,	200469
3	511333	filter	FC_EA	180818



Item	Order	Description	Model	OEM
1	510805	drain inlet		160301
2	510875	gasket	FC_, FC_A,	200410
3	510498	nut 1 1/2"	FC_CBT,	180109
4	510876	gasket	FC_LBT, FC_E,	200412
5	510803	elbow	FC_EA	160203
6	510356	nut 1 1/2"		180102



Item	Order	Description	Model	OEM
1	511334	filter		332006
2	511335	drain filter		180822
3	511336	drain inlet	FC_HR,	160309
4	510875	gasket	FC_HRA	200410
5	510498	nut		180109



Item	Order	Description	Model	OEM
1	510914	filter	F2, F3, F300, C30, C85, C140, LC380, LC380BT, G65, G66, G115, G131	330528
2	512215	filter	GF90, GF90A	H34430



Item	Order	Description	Model	OEM
1	510804	inlet filter	F2, F3, F300, C30	160603
2	510891	O-ring		200801
3	511338	inlet connector		180207
4	511339	O-ring	C33, C34	200807
5	511294	flange		180204




Item	Order	Description	Model	OEM
1	510469	protection plug		191057
2	510472	drain fitting	C85, C140, LC380, LC380BT, LC400,	180235
3	510832	gasket	GF90, GF90A	200906
4	510499	nut		180128



Item	Order	Description	Model	OEM
1	511340	filter	C95, C95E2, C95BT,	332002
2	510815	drain inlet	C155BT, C165,	180236
3	510832	gasket	C165E2, C165E2BT,	200906
4	510356	nut	C166, C166-2	180102



Item	Order	Description	Model	OEM
1	510851	flat filter	C34, LC380, LC380BT, LC400	180811
2	510482	flat filter	C85, C140	330568
3	510483	flat filter	C95, C95_, C155, C155_, C165, C165_, C166, C166-2	330586



Item	Order	Description	Model	OEM
1	511342	inlet hose	B10-B12, B20-B27, B10T-B12T, LBR_, LBR_H LBC_, LBC_A	200719
2	511347	outlet hose	B10-B12, B10T-B12T, LBR_, LBR_A	200369



Item	Order	Description	Model	OEM
1	511343	inlet hose	B20-B27	200319
2	511348	outlet hose	LBC__, LBC__A	200781



Item	Order	Description	Model	OEM
1	511186	inlet hose	FC__, FC__A,	200787
2	511354	outlet hose	FC__CBT, FC__E, FC__EA, FC__LBT, FC__HR, FC__HR__A	200789



Item	Order	Description	Model	OEM
1	511344	inlet hose	B13T-B19T, B__M	200732
2	511345	outlet hose	B13T-B19T	200733
3	511346	outlet hose	B__TM	200765



Item	Order	Description	Model	OEM
1	530559	inlet hose		200312
2	530599	outlet hose	F2, F3 (first series)	200311 200735




Item	Order	Description	Model	OEM
1	530593	inlet hose	B41, B42, LF320Lavline, F20, F55	200370
2	511337	outlet hose	B41, B42, F20	200372
3	530599	outlet hose	F55, LF320Lavline	200735, 200311




Item	Order	Description	Model	OEM
1	530582	inlet hose	F2, F3 (2. series), F300, F45, F65, LF280	200334
2	530586	outlet hose	F45, F65, LF280	200389



Item	Order	Description	Model	OEM
1	511349	inlet hose	BC__, BC__A, BC__HR, BR__, BR__A, FC43, FC43A	200778
2	511350	outlet hose	BC__, BC__A, BC__HR	200776
3	511351	outlet hose	BR__, BR__A	200777



Item	Order	Description	Model	OEM
1	530593	inlet hose		200312
2	511356	outlet hose	F80	200389



Item	Order	Description	Model	OEM
1	511352	inlet hose	BHC__, BHC__A,	201029
2	511353	outlet hose	BHC__S, BHC__HR, BHC__HRA	201030



Item	Order	Description	Model	OEM
1	530593	inlet hose	LF315, LF320,	200370
2	511354	outlet hose	LF320A, LF320CBT, LF320LBT, LF323, LF323A, LF350, LF350A	200789

Suitable for Comenda




Item	Order	Description	Model	OEM
1	530592	inlet hose	C30 (first series)	200355
2	530584	outlet hose		200354



Item	Order	Description	Model	OEM
1	530579	inlet hose	C30 (second series), C70, C75, C75M, LP360, LP360BT	200724
2	511357	outlet hose	C30 (second series)	200725
3	511226	outlet hose	C70, C75, C75M, LP360, LP360BT	200755



Item	Order	Description	Model	OEM
1	511358	inlet hose	C33, C34	200359
2	530588	outlet hose		200315




Item	Order	Description	Model	OEM
1	511359	inlet hose	C75BT	201019
2	511360	outlet hose		201020



Item	Order	Description	Model	OEM
1	511361	inlet hose	C85	200749
2	511584	outlet hose		200757



Item	Order	Description	Model	OEM
1	511208	inlet hose	C95, C95E2, C95BT,	200768
2	530544	outlet hose	C155, C155E2, C155BT, C165, C165E2, C165E2BT, C166, C166-2	200769



Item	Order	Description	Model	OEM
1	530577	inlet hose	C140, LC380,	200750
2	511362	outlet hose	LC380BT, LC400	200758



Item	Order	Description	Model	OEM
1	511363	inlet hose	LF400	200788
2	511364	inlet hose	LF450, LF450A, F90, F90A	201014
3	511354	outlet hose	LF400A, LF450, LF450A, F90, F90A	200789




Item	Order	Description	Model	OEM
1	511365	inlet hose	FC__BT, C__BT	201017
2	530581	inlet hose	LP__BT, LC__BT	200122
3	511366	outlet hose	FC__BT, C__BT, LP__BT, LC__BT	200759

Door components




Item	Order	Description	Model	OEM
1	510913	hinge	B_, B_T, B_TM,	321802
2	510920	hinge pin	F20-F80, LF280Lavline, LF320Lavline	341218




Item	Order	Description	Model	OEM
1	511375	door pin		342087
2	511376	spring	BHC_, BHC_A,	450234
3	511377	sleeve nut	BHC_S, BHC_HR,	261013
4	511378	nut	BHC_HRA	450829



Item	Order	Description	Model	OEM
1	510492	rod guide		160905
2	510957	end stop	B18, B19T, B41, B42, B18M, B19TM, F20-	190619
3	510491	door stay	F80	330209
4	510829	threaded part		250207



Item	Order	Description	Model	OEM
1	510492	rod guide		160905
2	510957	end stop	BHC_, BHC_A,	260503
3	511380	door stay	BHC_S, BHC_HR,	330235
4	511381	threaded part	BHC_HRA	342701
5	511382	shim		160838




Item	Order	Description	Model	OEM
1	511367	hinge right	BC_, BC_A,	441108
2	511368	hinge left	BC_HR, BR_,	441107
3	511369	hinge pin	BR_A, FC43, FC43A, LF_, LF_A, LF_BT	341921




Item	Order	Description	Model	OEM
1	511383	door pin	LBR_, LBC	341297
2	511384	hinge	FC_, FC_A, FC_BT,	321807
3	510920	hinge pin	FC_E, FC_EA, FC_HR, FC_HRA	341218



Item	Order	Description	Model	OEM
1	511370	gasket		160837
2	511371	holder		160909
3	511176	end stop	BC_, BC_A,	190644
4	511372	door stay	BC_HR, BR_,	330227
5	511373	threaded part	BR_A, FC43, FC43A	341922
6	511374	shim		160836




Item	Order	Description	Model	OEM
1	510492	rod guide		160905
2	510957	end stop	FC_, FC_A, FC_BT,	190619
3	511386	door stay	FC_E, FC_EA,	330233
4	511156	threaded part	FC_HR, FC_HRA	342010
5	511382	shim		160838




Item	Order	Description	Model	OEM
1	511370	gasket		160837
2	510492	rod guide		160905
3	510957	end stop	LF_, LF_A, LF_BT	190619
4	511154	door stay		330231
5	511156	threaded part		342010
6	511382	shim		160838



Item	Order	Description	Model	OEM
1	510911	door seal	B_, B_T, B_TM, F_, LF_Lavline	200901
2	511310	door seal	BC_	200918
3	511389	door seal	BHC_	200945




Item	Order	Description	Model	OEM
1	511390	door seal	LBR_, LBC	200215
2	511311	door seal 1000 mm	FC_, LF_	200923
3	510938	fixing plate		331764



Item	Order	Description	Model	OEM
1	510925	door catch	B_, B_T, B_TM, F2-	381403
2	512116	door catch	F300, LF_Lavline, BC_, BHC_A, HC_HR, BR_, BR_A, LBR_, LBC_, FC_, FC_A, FL_E, FC_HR, LF_LF_A, LF_BT	180506



Item	Order	Description	Model	OEM
1	510881	foam strip 6x2,5 mm		200433
2	510880	foam strip 8x4mm		200432
3	511391	foam strip 25x4mm		200402



Item	Order	Description	Model	OEM
1	511388	door handle	B10	170809
2	510493	door handle	B11-B12	170808
3	510453	door handle	B15-B16	170810
4	510454	door handle	B18-B19	170806


Hood components




Item	Order	Description	Model	OEM
1	510868	clamp	C30, C70, C75, C85,	191013
2	510869	clamp plate	C95, C140, C155,	191014
3	510988	pin	C165, C166, LP360, LC380, LC400	340493
4	510856	support		190110
5	510882	gasket	C30, C70, C75, LP300	200451
6	511397	supporting plate		330917




Item	Order	Description	Model	OEM
1	510478	door handle	B20-B42, LBR_, LBC, LF_	170801 170812
2	510818	door handle	B_T, B_TM, F_	210405



Item	Order	Description	Model	OEM
1	510867	bush	C85, C140	190632
2	510817	spacer		160530
3	511393	support block	C95, C155, C165, C166, LC380, LC400	190149
4	510991	support clip	C33, C34	440703
5	510350	handle support		190608 190637+ 190038




Item	Order	Description	Model	OEM
1	510864	spring locator		190607
2	510926	spring	C30, C70, C75, LP360	391312
3	510928	spring	C85, C95, C140, C155, C160, C165, LC380, LC400	391316



Item	Order	Description	Model	OEM
1	510992	spring locator		190616
2	510922	bush	C33, C34	330816
3	510927	spring		391313
4	510484	spring compressor		330207




Item	Order	Description	Model	OEM
1	510826	door guides right		180605
2	510827	door guides left	C30, C70, C75, LP360	180606
3	510881	foam strip		200433




Item	Order	Description	Model	OEM
1	511005	door guides	C33, C34, LC380, LC400,	180604
2	511202	door guides	C85, C140	180613
3	510948	door guides	C95, C155, C165, C166	180624
4	510889	gasket		200497


Electrical components




Item	Order	Description	Model	OEM
1	510918	switch panel	B10 - B12	460714
2	511017	switch panel	B18 - B19	460713
3	510963	switch panel	F20	460851
4	510961	switch panel	F45 - F80	460850




Item	Order	Description	Model	OEM
1	510726	fascia	B10T	460926
2	511398	fascia/ upper	B11T, B12T	460911
3	511399	fascia/ lower		460917
4	511400	fascia	B13T, B14T	460956




Item	Order	Description	Model	OEM
1	510960	fascia/ upper	B15T, B16T	460912
2	510999	fascia/ lower		460918
3	511401	fascia/ upper	B18T, B19T,	460913
4	511402	fascia/ lower	B15TM - B19TM	460919




Item	Order	Description	Model	OEM
1	511410	fascia	BHC433, FC43	461063
2	511408	fascia	BHC433A, FC43A	461108
3	511411	fascia	LF280/ 380, Lavline	461074
4	511412	fascia	LF320/ 323/ 350, LF320/ 323/ 350A, LE320 - BT, LF320LA	461101




Item	Order	Description	Model	OEM
1	511403	fascia	BR20/ 25, BC25/ 30, BHC25/ 30, BHC25S	461051
2	511404	fascia	BR20/ 25A, BC25/ 30A, BHC25/ 30A	461050
3	511405	fascia	BC25/ 30HR, BC30HRA	461057
4	511406	fascia	BHC30HR	461235




Item	Order	Description	Model	OEM
1	510997	fascia	F2/ 3	460146
2	511194	fascia	F300	460142
3	511413	fascia	FC_, FC_BT	461107
4	511414	fascia	FC_A	461138




Item	Order	Description	Model	OEM
1	511407	fascia	BHC30HRA	461232
2	511408	fascia	LBR200	461108
3	511409	fascia	LBR215/ 230, LBC_, LBC_A	461073




Item	Order	Description	Model	OEM
1	511415	fascia	C70, C85, C140	460921
2	511416	fascia	LP360, LC380/ 400	461075
3	511417	fascia	LP360BT, LC380BT	461194




Item	Order	Description	Model	OEM
1	400053	fascia	C75, C75M	461053
2	511418	fascia	C75BT	461192
3	400051	fascia	C95, C155	461025
4	511419	fascia	C95BT, C155BT	461193




Item	Order	Description	Model	OEM
1	511424	fascia	C95E2 (from No. 10912),	461227
2	400940	control p.c.b.	C155E2 (from No. 10912),	121267
3	400939	main p.c.b.	C165E2 (from No. 10912)	121230




Item	Order	Description	Model	OEM
1	511420	touch pad	FC54E	461254
2	511421	touch pad	FC54AE	461258
3	400933	control p.c.b.	FC54E/ EA	121277
4	400934	control box		121279



Item	Order	Description	Model	OEM
1	400052	fascia	C165	461052
2	400050	control p.c.b.		120288
3	379903	temperature sensor	FC543_, C_, E2, C165, C166, C166-2	120913




Item	Order	Description	Model	OEM
1	511422	touch pad	FC543E/ EA, FC543HR/ HRT	461127
2	400935	control p.c.b.	FC543E/ EA	121210
3	400936	control p.c.b.	FC543HR/ HRT	121211
4	400937	net board		121216



Item	Order	Description	Model	OEM
1	400942	p.c.b.	BHC_HR, BHC_HRA	121274
2	379904	temperature sensor		120952


Switches + Lamps




Item	Order	Description	Model	OEM
1	511423	fascia	C95E2 (to No. 10911),	461170
2	400938	control p.c.b.	C155E2 (to No. 10911),	121229
3	400939	main p.c.b.	C165E2 (to No. 10911), C165E2BT, C166, C166-2	121230



Item	Order	Description	Model	OEM
1	345017	rotary switch, 3 positions	B20, B20D, B24, B25, B26, B27, BC25/ 30A, BR20/ 30A, BHC25/ 30A	120708
2	345018	rotary switch, 4 positions	B23	120709
3	345031	rotary switch, 2 positions	B41, B42, LF280/ 320, Lav line	120714



Item	Order	Description	Model	OEM
1	345019	rotary switch, 2 positions	B10-B19, B10T-B19T, B15TM-B19TM, BC25/ 30, BR20/ 30, BHC25/ 30, G66/ 131 (old)	120712
2	345837		BC25/ 30HR, BC30HRA	120734
3	345838	rotary switch, 2 positions	BHC30HR/ HRA, LF320CBT, LF320LBT, FC53/ 54CBT, FC53/ 54LBT, GF_	120744



Item	Order	Description	Model	OEM
1	345054	rotary switch, 2 positions	BHC433, FC43, FC43A	120735
2	345839	rotary switch, 2 positions	BHC433A, FC_A	120740
3	345009	rotary switch, 3 positions	F20, LF320, LF320A, LF320LA	120722



Item	Order	Description	Model	OEM
1	345012	rotary switch, 5 positions	F55, F65, F80	120728
2	345840	rotary switch, 2 positions	LF323/ 350, LF323/ 350A, LF400A, LF450/ A, F_M/ A	120737
3	345007	rotary switch, 4 positions	C30	120713



Item	Order	Description	Model	OEM
1	345024	rotary switch, 2 positions	C70, C75, C75M, C85, C95, C140, C155	120729
2	345841	rotary switch, 2 positions	C75BT	120747
3	345842	rotary switch, 2 positions	C95, C155BT, G_L, G50LM, G_	120716



Item	Order	Description	Model	OEM
1	110062	knob	B20-B42, F2, F3, F300, C30, C33, C34	180111
2	110093	knob	BC_, BR_, BHC_, LF_, FC_, LC_, C75-C95, C155	450323
3	110061	knob	B10-B19, F_, C70, C170	450316
4	510923	spring		440817



Item	Order	Description	Model	OEM
1	510375	switch panel	B10-B19, F45	460776
2	511215	switch panel	F20	460777
3	510968	switch panel	F55-F80	460778



Item	Order	Description	Model	OEM
1	345000	push button, 2-pole-changeover (start)		130421
2	345010	push button, 2-pole (regeneration)	B_, B_T,	130423
3	345014	push button, 2-pole-changeover	B_TM, F_	130422, 130429
4	345030	push button, 2-pole-changeover (drain pump)		130424



Item	Order	Description	Model	OEM
1	345076	push button, 2-pole-changeover	B_, B_T,	130444
2	345123	switch, 2-pole-changeover	B_TM, F_,	130447
3	510281	blind cap	C95, C155	160733



Item	Order	Description	Model	OEM
1	345843	push button, 2-pole (drain pump)	LF_	130471
2	345844	switch/ lamp (regeneration)		130470
3	345845	switch	LBR_, LBC_	130460
4	345846	push button		130459



Item	Order	Description	Model	OEM
1	345130	push button, 1-pole	BC_, BR_, BHC_, LF_,	130449
2	345131	housing-single, 28 x 28	FC_, C75/ 95/ 115, LP_BT	190140
3	345132	button/ green	BC_, BR_, LF	450320
4	345133	button/ grey		450321



Item	Order	Description	Model	OEM
1	345856	24 V/ cycle	LF_ BT, LC-	130180
2	345857	230V/ on/cycle	BT, LP_BT	130147



Item	Order	Description	Model	OEM
1	345847	button/ green (start)		450326
2	345848	button/ blue (cold rinse)		450332
3	345849	button/ grey (regeneration)		450327
4	345850	button/ grey (cold rinse)	BHC_, LF_,	450329
5	345851	button/ grey (start)	FC_, LP_BT,	450331
6	345852	button/ grey (drain pump)		450328



Item	Order	Description	Model	OEM
1	345858	push button/ black		130413
2	345972	push button/ black	G65	130439
3	345089	connector block		130411




Item	Order	Description	Model	OEM
1	345050	switch, 2-pole-changeover	F2/ F3 (old)	120711
2	345051	switch, 2-pole		120704
3	359029	230V/ on	B20-B42	130125
4	359030	230V/ ready		130126



Item	Order	Description	Model	OEM
1	345859	lamp/ cycle, 24V		130175
2	345860	double lamp/ ready + on, 24V	LF400A	130178
3	345861	switch + lamp/ regeneration, 24V	LF400A, GF90, GF90A	130472
4	345856	lamp/ cycle, 24V		130180
5	345857	double lamp/ ready + on, 230V	GF90, GF90A	130147



Item	Order	Description	Model	OEM
1	359010	230V/ on	B_, B_T,	130134
2	359011	230V/ ready	B_TM, F_,	130135
3	359012	230V/ cycle	LBR_, LBC_,	130136
4	510281	blind cap	C70, C85, C140	160733



Item	Order	Description	Model	OEM
1	345853	lamp/ on, 230V		130168
2	345854	lamp/ ready, 230V	LF450,	130169
3	345855	lamp/ cycle, 230V	LF450A,	130152
4	345844	switch + lamp/ regeneration, 230V	FM90, FM90A	130470



Item	Order	Description	Model	OEM
1	345853	230V/ on		130168
2	345854	230V/ ready	LF_, LC_, LP_,	130169
3	345855	230V/ cycle		130152



Item	Order	Description	Model	OEM
1	359031	signal lamp, 230V, green	BC_, BHC_, FC_	130157
2	359032	signal lamp, 230V	C75, C95, C155	130159
3	359801	signal lamp, 12V	BHC_HR	130182
4	359802	signal lamp, 24V	FC_BT, FC_H, C_BT	130181



Item	Order	Description	Model	OEM
1	359803	neon cover, green		130704, 130708
2	359804	neon cover, yellow		
3	359805	neon cover, red		130706
4	359806	neon cover, clear		130707



Item	Order	Description	Model	OEM
1	359138	signal lamp, 230 V, red		130103
2	359139	signal lamp, 230 V, green	F2, F3, F300,	130115
3	359140	signal lamp, 230 V, yellow	C30, C33	130116
4	359036	signal lamp, 230 V, clear		130123



Item	Order	Description	Model	OEM
1	359026	signal lamp, 230 V, red		130120
2	359027	signal lamp, 230 V, green	C33, C34	130121
3	359021	signal lamp, 230 V, clear		130122




Item	Order	Description	Model	OEM
1	359023	signal lamp, 24 V, green		130117
2	359024	signal lamp, 24 V, yellow		130119
3	359025	signal lamp, 24 V, red		130118
4	359047	signal lamp, 24 V, clear		




Item	Order	Description	Model	OEM
1	359129	signal element, 24V		130170
2	359262	socket/ green	G_L	130711
3	359261	socket/ red		130710


Timers



Item	Order	Description	Model	OEM
1	360011	120", 230V, 3 cams	B10-B19	120225
2	360043	120", 230V, 4 cams	B10T-B19T, B15TM-B19TM, LBR_, LBR_H	120262
3	360006	120", 230V, 2 cams	B20-B27	120213




Item	Order	Description	Model	OEM
1	360007	210", 230V, 3 cams	B31, B32, B41, B42,	120208
			F2, F3, C33, C34	
2	360008	180", 230V, 3 cams	F300, F55 (old)	120212
3	360015	180", 230V, 3 cams	C30	120217




Item	Order	Description	Model	OEM
1	360012	150", 230V, 3 cams	F45/ 65 (old), R40	120220
2	360014	20", 230V, 4 cams/ regeneration	B12, B12T, B14T, B16, B16T, B16TM, B19, B19T, B19TM, B25, B27, B32	120214



Item	Order	Description	Model	OEM
1	360086	120", 230V, 4 cams	BC_, BCA, BC30HR, BR_, BR_A, BHC25/ 30, BHC25/ 30A	120279
2	360088	90"/ 180", 230V, 5 cams	BHC433, BHC433A, FC43, FC43A, FC53	120292
3	360085	180", 230V, 5 cams	F20	120296




Item	Order	Description	Model	OEM
1	360044	120", 230V, 4 cams	F45, LF280, LF320, LF315	120263
2	360048	120"/ 180", 230V, 5 cams	F55, LF320, LF320A, LF320LA	120269
3	360047	100"/ 150", 230V, 5 cams	F65, LF323, LF323A	120268



Item	Order	Description	Model	OEM
1	360049	75"/120", 230V, 5 cams	F80, LF350, LF350A, LF450, LF450A	120270
2	360288	120"/180", 230V	FC54	121217
3	360002	100"/150", 230V	FC533, FC543, FC544, FC533A, FC543A, FC544A	121208




Item	Order	Description	Model	OEM
1	360087	20", 230V, 3 cams (regeneration)	BC_A, BR_A, BHC_A, LF_A, FC_	120291
2	360080	20", 230V, 3 cams (regeneration)	LBR_A, LBC_A	120277
3	360285	18", 230V (regeneration)	BC_HRA	121220




Item	Order	Description	Model	OEM
1	360041	120", 230V, 3 cams (drain pump)	BHC_, FC_, LF_, FM	120290
2	360286	120", 230V (drain pump)	BC_	120296
3	360050	90"/120"/180", 230V, 6 cam	C70, C75M, LP360	120275




Item	Order	Description	Model	OEM
1	360045	75"/120"/180", 230V, 6 cams	C75, C85	120266
2	360287	65"/120"/180", 230V, 6 cams	C95, LC380	121218
3	360046	60"/85"/120", 230V, 6 cam	C140, C155, LC400	120267



Item	Order	Description	Model	OEM
1	360013	360", 230V, 3 cams	G50	120222
2	360010	90", 230V, 3 cams	G66	120228



Item	Order	Description	Model	OEM
1	400943	control p.c.b.	FC_BT, LF_BT, C_BT	121239
2	400944	control p.c.b.	FC533A, FC543A, FC544A	121237



Item	Order	Description	Model	OEM
1	400945	electronic timer	G65, G115	120226
2	400946	electronic timer	G_L	120254

Pressure switches



Item	Order	Description	Model	OEM
1	541010	50/30	B10-12, B20-B27, LBR_, LBR_A, LBC_, LBC_A, F45, F65, F80, LF280/320, FC_, FC_A, C30, C85, C140, C_BT, LP360BT, LC_, LC_BT	130605
2	541000	110/75	B15-19, B41, B42, B13T-B19T, B15TM-B91TM, F2/3/300 (new), F20	130607
3	541024	60/40	BC_, BC_A, BR_, BR_A, FC43, FC43A	130617

Suitable for Comenda



Item	Order	Description	Model	OEM
1	541039	45/ 22	BC_HR, BC30HRA, LF_	130621
2	541307	30/ 12	BHC_, BHC_A	130629
3	541012	70/ 40	F2/ 3/ 300 (old), F80, C30, C33, C34, C70, C75, LP360	130604




Item	Order	Description	Model	OEM
1	541308	110/ 70	FC_BT	130628
2	541023	190/ 80	C95, C155, C165, C166	130616




Item	Order	Description	Model	OEM
1	541309	48/ 28	FC_HR, FC_HRA, FC_HRT, FC_HRTA, C_BT, LP360BT, LC380BT	130622
2	541310	4,5mbar		130625
3	541109	Y-piece	universal	190314


Thermostats



Item	Order	Description	Model	OEM
1	390006	thermostat, 0 - 95 °C	B_, B_T, B_TM, BC_, BR_, BHC_, BHC_A, F_, LF_, FC43, FC_BT, C30-C155, LP_, LC_	120501
2	390014	thermostat, 40°- 78 °C, 47°- 85 °C	LBR_, LBC_, FC_, C95, C155, C_BT, LP360BT, LC380BT	120525



Item	Order	Description	Model	OEM
1	390022	thermostat, 0 - 90 °C	LF_, FC_, FC_A, C75, C75M, C_BT, LP_	120522
2	390023	safety thermostat, 90 - 115 °C	F45-F80, C70, C85, C140, C155	120519



Item	Order	Description	Model	OEM
1	390469	safety thermostat, 2-pole 105 °C	BHC_, FC54C	120526
2	390024	safety thermostat, 110 °C	B_T, B_TM, BC_, BR_, LBR_, LBC_, F20, LF_, FC_, C75, C75M, C95, C155, C_BT, LP_, LC_	120523

Contact thermostats



Item	Order	Description	Model	OEM
1	390089	55 °C	B_	120509
2	390025	50 °C-closer, 58 °C-opener	B_T, B_TM, BC_, BR_, BHC_,	120524
3	512154	gasket	BHC_A, LBR_, LBC_, LF315, FC43	200494



Item	Order	Description	Model	OEM
1	110310	bezel		191040
2	110100	knob	universal	450315
3	110918	knob		180120
4	110062	knob (with screw)		180111


Thermostat pockets




Item	Order	Description	Model	OEM
1	510987	1 pocket (short)	universal	450519
2	510935	1 pocket		450515
3	510986	2 pockets		450514
4	511425	3 pockets		450520



Item	Order	Description	Model	OEM
1	345052	micro switch	C34	120319



Item	Order	Description	Model	OEM
1	345358	250V, 0,4A	FC_	120356
2	345116	250V, 0,4A	C95, C155, C165, C166	120348
2	345122	24V, 8A	G65, G115	120333, 120342
4	511228	float switch	FC_BT, C_BT, LP_BT, LC_BT	120358



Item	Order	Description	Model	OEM
1	511426	1 pocket	FC_HR, BHC_HR	450521
2	521122	gasket	universal	460502
3	510331	nut, 1/2"		270101



Item	Order	Description	Model	OEM
1	345057	limit switch	C30, C33, C70	120320
2	345058	limit switch	C34	120322



Item	Order	Description	Model	OEM
1	345059	start/ rinse	B10-B18, B10T-B12T	120323
2	345073	rinse	B12, B15-B18	120332
3	345072	start	B15-B19	120329
4	345078	push button	130419, 130420	



Item	Order	Description	Model	OEM
1	345075	limit switch	C75, C85, C95, C140, C155, LP360, LC380, LC400	120343
2	345862	limit switch	G75, G75L, G125, G125L	120326
3	345040	limit switch	C30-C34 (old)	120316




Item	Order	Description	Model	OEM
1	345059	1 changeover	LBR_, LBC_, B41, B42	120323
2	345125	1 changeover	B41, B42	120324
3	345121	with magnet	BC_, BR_, BHC_, FC43	120346



Item	Order	Description	Model	OEM
1	345032	1 changeover	F_, LF_	120313
2	510924	pin		381002
3	510917	bush		330820
4	345074	1 changeover	B13T, B14T	120341



Item	Order	Description	Model	OEM
1	370015	single, 230V	LBR_, LBC_, FC_, FC_E, FC_BT, FC_HR, F2/ 3/ 3000, F45-F80, LF_, LF_BT, C30-C155, C165-E2, C166, C166-2, LC_	120112, 120145, 120196
2	370019	double, 230V	B16/ 19, B12T, B14T, B16T/ TM, B19T/ TM, B23-27, B41/ 42, BC_, BC_HR, BR_, FC43, C165	120142, 120143, 120197
3	370021	double, 230V	B15/ 18, B10T, B11T, B13T, B15T/ TM, B19T/ TM, B20, BHC_, BHC25S, BHC_HR, F20	120146



Item	Order	Description	Model	OEM
1	370011	double, 230V (with reducer)	B12, B16, B19, B12T, B14T, B16T/ TM, B19T/ TM, B25, B27, LBR_A, LBC_A, FC_A, FC_EA, FC_HRA, LF_A	120144
2	370255	triple, 230V (with reducer)	BC_A, BC_HRA, BR_A, FC43A	120179
3	370256	triple, 230V	BHC_A, BHC_HRA	120175



Item	Order	Description	Model	OEM
1	370102	3/4"- 1 1/2", 24V		120141
2	371021	solenoid coil, 24V		630967

Solenoid valves/ Sirai L180 (for water)




Item	Order	Description	Model	OEM
1	370047	1/2", 230V		120174
1	370329	1/2", 24V		120131
1	370252	3/4", 24V		120122
1	370330	1", 24V		120123
2	371070	solenoid coil, 24V (Z610A)		630948
2	371071	solenoid coil, 230V (Z610A)		

Solenoid valves/ Sirai L153 (for steam and water)




Item	Order	Description	Model	OEM
1	370079	3/4", 230V		120167
1	370325	3/4", 24V		120165
1	370327	1", 24V		120166
2	371077	solenoid coil, 230V, 3/4"	(Z114A)	
2	371160	solenoid coil, 24V, 3/4"	(Z114A)	
2	371162	solenoid coil, 24V, 1"	(Z114A)	630976
3	371168	membrane, 3/4"		630628
3	371169	membrane, 1"		630629

Solenoid valves/ Sirai L145 (for steam)



Item	Order	Description	Model	OEM
1	370318	1/2", 24V		120161
1	370324	3/4", 24V		120162
1	370311	1", 24V		120163
2	371158	solenoid coil, 24V, 1/2"		630973
3	371068	solenoid coil, 24V, 3/4"/ 1"		630972

Relays




Item	Order	Description	Model	OEM
1	380311	1 NO + 1 NC, 20 A, 230V	BHC_, HR, FC	120460
2	380131	3 changeover, 16A, 230V	BC_HR, LP_, C75, C95, C155, C165	120459
2	380404	3 changeover, 16 A, 24V AC		120445
3	380634	1 changeover, 12V DC	FC_HR	120465



Item	Order	Description	Model	OEM
1	380403	3 changeover, 230V	C70, C85, C140	120447 120459
2	380129	2 changeover, 5A, 24V		120449
3	380633	1 changeover, 16 A, 24V DC	LF400A	120480

Contactors



Item	Order	Description	Model	OEM
1	380212	3 NO + 1 NC, 230V, AC1, 20A	BC_HR, BHC_HR, BHC433, FC_A, FC533, FC543, FC544, LF400, GF90	120461
1	380213	3 NO + 1 NO, 230V, AC1, 20A		
2	380245	3 NO + 1 NC, 230V, AC1, 25A	FC_E, F45-F80, F90M, F2/ 3/ 300, LF323, LF350, LP_	120444
2	380244	3 NO + 1 NO, 230V, AC1, 25A	FC_C, LF320C	120438
2	380249	3 NO + 1 NC, 24V		
2	380248	3 NO + 1 NO, 24V	G_L	120429, 120428
3	380262	3 NO + 1 NC, 230V	C33/ 34, C95, C155, C166, LC380, LC400	120435, 120434

Transformers



Item	Order	Description	Model	OEM
1	400049	70 VA, 208-380-415-440, 230V		120605
2	400947	150 VA, 220-240-380-415, 24V	G_L	120608




Item	Order	Description	Size	Pack Qty	OEM
1	358075	fuse holder	10,3 x 38mm		150710
2	358024	fast-acting, 8A (GL)	10,3 x 38mm	1pieces	130245
2	358025	fast-acting, 12A (GL)	10,3 x 38mm	1pieces	130246
2	358027	fast-acting, 16A (GL)	10,3 x 38mm	1pieces	130247
2	358028	fast-acting, 20A (GL)	10,3 x 38mm	1pieces	130248
3	358033	slow-acting, 1A (AM)	10,3 x 38mm	1pieces	130259
3	358034	slow-acting, 2A (AM)	10,3 x 38mm	1pieces	130260
3	358035	slow-acting, 4A (AM)	10,3 x 38mm	1pieces	130230
3	358036	slow-acting, 6A (AM)	10,3 x 38mm	1pieces	130231
3	358037	slow-acting, 8A (AM)	10,3 x 38mm	1pieces	130232
3	358039	slow-acting, 12A (AM)	10,3 x 38mm	1pieces	130234
3	358040	slow-acting, 16A (AM)	10,3 x 38mm	1pieces	130235
3	358041	slow-acting, 25A (AM)	10,3 x 38mm	1pieces	130236
4	358596	slow-acting, 250 mA	5 x 20 mm	10pieces	130273
4	358600	slow-acting, 1A	5 x 20 mm	10pieces	130264
4	358602	slow-acting, 1,6A	5 x 20 mm	10pieces	130265
4	358603	slow-acting, 2A	5 x 20 mm	10pieces	130270
4	358609	slow-acting, 5A	5 x 20 mm	10pieces	130274
4	358607	slow-acting, 6,3A	5 x 20 mm	10pieces	130275


Dosing pumps




Item	Order	Description	Model	OEM
1	361002	dosing pump (rinse aid)		620120
2	510297	membrane		630614
3	510298	non-return valve		200444
4	510338	union nut		170701
5	510299	hose connector		180306



Item	Order	Description	Model	OEM
1	361010	dosing pump (rinse aid)		620788
2	361371	membrane	LF_BT, C_BT, LP_BT, LC_BT	630632
3	361383	non-return valve		200942



Item	Order	Description	Model	OEM
1	361025	dosing pump		620242
2	361130	internal tube, compl.		200607
3	361128	tube		
4	361118	suction tube		180719




Item	Order	Description	Model	OEM
1	361158	dosing pump		440632
2	361134	internal tube comple.		200608
3	361058	bottle weight/ filter		180726




Item	Order	Description	Model	OEM
1	361152	dosing pump		440627
2	361134	internal tube, compl.		
3	361141	bottle weight/ filter		

Heating elements


Tank heating elements



Item	Order	Description	Model	OEM
1	415012	1500W, 230V	B10-B42, B_T/ TM, LBR_, LBC_, F20	110235
2	415062	1275W, 230V	BC_, BR_, FC43	110260
3	415198	2000W, 230V	BHC_	110269



Item	Order	Description	Model	OEM
1	416270	500W, 230V	BHC_HR	110271
2	415756	2000W, 230V	FC_, LF_, F_M	110263
3	415016	3000W, 3 phases 230V	F2/ 3/ 300, C30, C70-C166, LP_, LC_, GF_	110227



Item	Order	Description	Model	OEM
1	415015	1500W, 230V	F300	110228, 110229
2	415061	2400W, 230V	F45-F80, LF280/ 320	110373
3	415017	1500W, 230V	F2, F3, C30	110208
4	415019	3000W, 230V	C33/ 34	110226

Accessories (tank-heating elements)



Item	Order	Description	Model	OEM
1	510418	O-ring, Ø10 mm		200810
2	510416	gasket, Ø10 mm		200415
3	520231	nut, M10 x 1		
4	510408	O-ring (heating elements)		200810
5	510405	gasket, 1 1/4"		
6	520232	nut, 1 1/4"		

Boiler heating elements



Item	Order	Description	Model	OEM
1	415013	2400W, 230V	B10-B27	110364
2	415014	3000W, 230V	B_T/ TM, B41/ 42, BC_, BR_, FC34, F20	110366
3	416271	5000W, 3 phases 230V	BC30HR380	110391



Item	Order	Description	Model	OEM
1	415020	4500W, 3 phases 230V	F2, F3, F55-F80, LF320, LF323, C30, C70, C75, C85, L95, LP360, G_L, G_	110331
2	415021	6000W, 3 phases 230V	LF350, C33, C34, C75BT, C75M, C95, C140, LC380, LF400, LF450, F_M, GF_, G_L, G_	110349
3	415022	9000W, 3 phases 230V	C155, L165, L166, LC400, G_L, G_	110362, 110365



Item	Order	Description	Model	OEM
1	416272	2500W, 230V	LBR_, LBC_	110262
2	416273	3200W, 230V	BHC25/ 30	110397
3	416274	5000W, 3 phases 230V	BHC30HR380, BHC433	110398
4	510408	gasket		200820

Conveyor belt-heating elements



Item	Order	Description	Model	OEM
1	415670	8000W, 3 phases 230V		110343
2	415023	12500W, 3 phases 230V		110367, 110369
3	510409	gasket		200815




Item	Order	Description	Model	OEM
1	416275	2200W, 230V	FC53/ 54L	110361
2	415060	3000W, 230V	FC53, FC54, F300, F45, LF280-LF323	110363
3	415019	3000W, 3 phases 230V		110226

Accessories (boiler heating elements)




Item	Order	Description	Model	OEM
1	510408	gasket 47,5 mm		200820
2	510409	gasket	universal	200815
3	520235	flange		
4	520357	protective cap		161123

Boilers




Item	Order	Description	Model	OEM
1	511001	boiler	B_, B_T/ TM, LBR_, LBC_	330334, 330316
2	511427	boiler	BC_, BR_, FC43	330340
3	511428	boiler	BHC_	330353



Item	Order	Description	Model	OEM
1	511000	boiler	F_ (outer F20), LP_, LC_, FC_, LF_, C_	330307, 330342, 330331
2	511429	boiler	FC_BT, C_BT, LP_BT, LC_BT	330352

Pumps

Drain pumps/booster pumps




Item	Order	Description	Model	OEM
1	500055	drain pump, 100W, 230V	universal	100342
2	500399	pressure pump, 73 W, 230V	FC_BT, C_BT, LP_BT, LC:BT	100747
3	500030	150 W, 230V		100647



Item	Order	Description	Model	OEM
1	500011	0,10 HP, 230V	B10-B12, B20	100660, 100370, 100628
2	500015	0,20 HP, 230V	B15-19, B10T-12T, LBR_, LBC210	100303, 100701
3	500019	0,30 HP, 230V	B13T/ TM-19TMM, BC_, BR_, LBC215/ 275, FC43	100702



Item	Order	Description	Model	OEM
1	500510	0,30 HP, 230V	BHC (to No. 9400/ 801)	100760
2	500511	0,30 HP, 230V	BHC (from No. 9401/ 801)	100785
3	500020	0,25 HP, 230V	B23-B27	100376



Item	Order	Description	Model	OEM
1	500006	0,4 HP, 230V	F300, F20, F45, B31, B32, B41, B42, P40	100375
2	500016	0,6 HP, 230V	F2/ 3, F55, F65, FC_, LF280-323, R70	100399



Item	Order	Description	Model	OEM
1	500127	0,6 HP, 230V	FC_, LF28-323	100740
2	500033	0,5 HP, 230V		100346



FIR1222

Item	Order	Description	Model	OEM
1	500009	0,50 HP, 230V		100363



1

FIR1241



2

FIR1225

Item	Order	Description	Model	OEM
1	500111	1,5 HP, 400V (3 ph)	LC380, LC400	100663
2	500023	1,5 HP, 400V (3 ph)		100634



1

FIR1223



2


FIR1219/ A

Item	Order	Description	Model	OEM
1	500086	0,75 HP, 230V	F3 (old)	100365
2	500017	1 HP, 230V	F80, C30, C70, C75, LF450	100384, 100672



1

FIR1204



2

FIR1205

Item	Order	Description	Model	OEM
1	500018	2,0 HP, 400V (3 ph)	C33, C34, C140, C155, C165, C166	100361, 100716
2	500031	2,7 HP, 400V (3 ph)		100373



1



2

Item	Order	Description	Model	OEM
1	500512	1 HP, 230V	LF350	100777
2	500513	1 HP, 230V	LP360	100727



Item	Order	Description	Model	OEM
1	500012	3,0 HP, 400V (3 ph)		100387



1

FIR1219



2

FIR2241

Item	Order	Description	Model	OEM
1	500004	1,5 HP, 400V (3 ph)	C85, LF400, F90M	100707
2	500058	1,5 HP, 400V (3 ph)	C95	100717



1



2



3



4



5



Pumps		1 Impellor		2 Mechanical seal		3 Housing gasket		4 Pump cover		5 Capacitor	
Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM
500004	100707	510529	631656	510692	630510	510552	630410	511187	630113	--	--
500006	100375	510358	631624	510693	630501	510399	630413	510950	630116	365015	631206
500009	100363	511210		510692	630510	510552	630410	511187	630113	365014	631207
500011	100370	510383	631640	510695	630514	509002	630416	510510	630125	--	--
500012	100387	510604	631618	510693	630501	510551	630441	510503		365014	631207
500015	100701	521204	631640	510695	630514	509002	630416	510510	630125	365017	631208
500016	100399	510358	631624	510693	630512	510399	630413	510950	630222	365015	631206
500017	100384	510600	631627	510692	630510	510552	630410	510508	630113	365014	631207
500018	100716	510604	631618	510693	630501	510551	630411	510531	630114	--	--
500019	100702	521203	631660	510695	630514	509002	630416	510510	630125	365017	631208
500020	100376	521207	631625	510695	630514	521701	630414	521501	630118	365015	631206
500023	100634	510602		510693	630501	510551	630411	521513		--	--
500030	100647	521202		510690		509002	630416	510510	630125	--	--
500031	100373	510612		510693	630501	510551	630411	510531	630114	--	--
500033	100346	510607		510692	630510	510552	630410	521510		365014	631207
500058	100717	510602	631667	510693	630501	510551	630411	510531	630114	--	--
500086	100365	521267	631619	510692	630510	510551	630410	510508	630113	365014	631207
500111	100663	510357	631653	510693	630501	510551	630411	510531	630114	--	--
500127	100740	510608	631683	510693	630501	521702	630419	521505	630129	365015	631206
500399	100747	521204	631640	510695	630514	509002	630416	510384	630131	365017	631208
500510	100760	521225	631689	510703	630524	521704	630421	521519	630133	365012	631216
500511	100785	521230	631695	510703	630524	521706	630424	521526	630135	365017	631208
500512	100777	521246	631674	510702	630526	521714	630420	521539	630130	365021	631202
500513	100727	521246	631674	510703	630522	521714	630420	521539	630130	365021	631202

