

# THE ORIGINAL PORTABLE DANCE FLOOR

SICO's ORIGINAL PORTABLE DANCE FLOOR is used and recommended by more hotels, clubs, and convention centers than any other portable dance floor on the market. Here's why:

- SICO's superior manufacturing process guarantees the squareness of every panel, making set-up and take-down much easier—and eliminates gaps between panels.
- SICO uses a harder T-6 aluminum metal feature strip which protects the edges of each panel, adding extra years of use and durability.
- All SICO ORIGINAL parquet panels are 3' x 3' (914mm x 914mm). No odd sizes to deal with, allowing easier set up.
- The unique helicoil insert protects and secures the set screw allowing for longer life.
- All panels make 100% floor contact so there is no possibility of breakthrough.
- SICO's U-shaped caddies hold up to 25 panels, with slots to keep trim neatly organized for quicker installation.
- Panels weigh 40 lbs. (18kg) and are shipped two per carton at 80 lbs. (36kg).

SICO uses only the highest quality parquet. In addition, a high-grade polymer coating on the back of the panels aids in resisting moisture penetration.

SICO's Visi-Trim edging provides a modest 11° slope to every floor with its broad 5" width (127mm). In addition, the trim has a gold anodized finish that highlights the edges of the dance floor.



The Natural Oak and Heritage Oak floors are protected with a rugged polyurethane finish.



# HOW MUCH DANCE FLOOR DO YOU NEED?\*

\* Assume that only one-third of your guests will dance, so the number of dancers shown in these graphs is only 33% of your total guests.

## ORIGINAL and CAM-LOCK Dance Floor Panels 3 ft. x 3 ft. (91cm x 91cm)

FLOOR SIZE	NUMBER OF PANELS	NUMBER OF DANCERS	NUMBER OF CADDIES
6'x9' (183cm X 274cm)	6	12	1
9'x9' (274cm x 274cm)	9	18	1
9'x12' (274cm x 366cm)	12	24	1
9'x15' (274cm x 457cm)	15	30	1
12'x12' (366cm x 366cm)	16	32	1
12'x15' (366cm x 457cm)	20	40	1
12'x21' (366cm x 640cm)	28	56	2
15'x18' (457cm x 549cm)	30	60	2
15'x21' (457cm x 640cm)	35	70	2
15'x24' (457cm x 732cm)	40	80	2
15'x27' (457cm x 823cm)	45	90	2
18'x24' (549cm x 732cm)	48	96	2
18'x27' (549cm x 823cm)	54	108	3
18'x30' (549cm x 914cm)	60	120	3
21'x27' (640cm x 823cm)	63	126	3
21'x30' (640cm x 914cm)	70	140	3
21'x33' (640cm x 1006cm)	77	154	4
27'x27' (823cm x 823cm)	81	162	4
24'x33' (732cm x 1006cm)	88	176	4
30'x30' (914cm x 914cm)	100	200	4
30'x33' (914cm x 1006cm)	110	220	5
30'x36' (914cm x 1097cm)	120	240	5

Contact your SICO sales representative to discuss your specific dance floor needs.